

# Pearl

# r.e.d.box

Real • Electronic • Drums



R B M 2 0  
O W N E R S M A N U A L

INTRODUCTION .....	1
CONNECTION DIAGRAM .....	1
GETTING STARTED .....	2
RESETTING THE MODULE TO FACTORY DEFAULTS .....	2
CHECK FOR UPDATES .....	2
RIDE CYMBAL SETUP .....	2
DEACTIVATE WRITE PROTECTION .....	3
THE BASICS .....	3
NAVIGATING MENUS & ADJUSTING SETTINGS .....	3
KITS .....	4
VOICES: LAYERS & INSTRUMENTS .....	4
VOLUME .....	4
SEQUENCES .....	5
STORING DATA .....	5
UTILITIES .....	6
REAR PANEL FEATURES .....	6
TOP PANEL FEATURES .....	7-8
KITS, VOICES, ACCOMPANIMENT & INSTRUMENTS .....	8
SELECTING A KIT .....	8
EDITING INSTRUMENTS IN A KIT .....	9
EDITING ACCOMPANIMENT IN A KIT .....	9
EDITING VOICE & ACCOMPANIMENT PARAMETERS .....	10-12
EDITING MIDI PARAMETERS .....	12-13
EDITING EFFECTS PARAMETERS .....	13-16
KIT SELECT SETUP .....	16
SEQUENCES .....	17
PLAYING SEQUENCES .....	17
RECORDING SEQUENCES .....	18
EDITING SEQUENCES (DRUMS) .....	18
EDITING SEQUENCES (ACCOMPANIMENT) .....	19
SETTING UP THE CLICK TRACK .....	20
EDITING QUANTIZATION SETTINGS .....	21
STORING & COPYING DATA .....	22
NAMING .....	22
STORING & COPYING KITS .....	22
COPYING INSTRUMENTS .....	23
STORING SEQUENCES .....	23
STORING TRIGGER SETTINGS .....	24
TRIG. EDIT MENU .....	24
TRIGGER INPUT PARAMETERS .....	24
TRIGGERING PARAMETERS .....	25
VELOCITY CURVE .....	26
MODE (RIDE BOW & BELL) .....	26
HI-HAT CALIBRATION .....	27
STORING TRIG. EDIT SETTINGS .....	27
EXPLORING OPTIMAL SENSITIVITY AND THRESHOLD SETTINGS .....	27
UTILITIES MENU .....	28
GENERAL .....	28
CLICK (F1) .....	28
MIDI (F2) .....	30
TRIG (F3) .....	31
SYS (F4) .....	31
UPDATING THE MODULE .....	33
MIDI SETUP .....	33
USING THE RBM-20 TO TRIGGER SOUNDS FROM A SOFTWARE DRUM MODULE .....	34
USING AN EXTERNAL MIDI DEVICE WITH THE RBM-20'S SOUND LIBRARY .....	35
MIDI IMPLEMENTATION CHART .....	36
RBM-20 SEQUENCES .....	36
RBM-20 KITS .....	37
RBM-20 INSTRUMENTS .....	38-41


## INTRODUCTION

Welcome to the Pearl Redbox drum module! The RBM-20 includes lots of high-fidelity drum, percussion, and accompaniment sounds giving you the sonic realism of acoustic drums but with the convenience and flexibility of electronic drums.

This manual details all the RBM-20 module's features. If you want to learn fast so you can dive right into playing, refer to the included Quickstart Guide. Or, for a brief overview of the module's features, see the BASICS chapter. Of course, we also recommend reading through this manual so you can take full advantage of all the amazing functions of the RBM-20.

Pearl Corporation

## CONNECTION DIAGRAM



- Connect your electronic drum set's triggers to the corresponding inputs on the module with the appropriate 1/4" cables. Dual-zone pads or cymbals (e.g., a drum with head and rim triggers or a cymbal that can produce bow and bell sounds) will require TRS cables to trigger both zones.
- Plug 1/4" TS cables from the MAIN OUT or AUX OUT to an amplifier, mixer, or speaker system. (For mono sound, you can connect only one output.)
- You can connect a set of 1/4" TRS headphones to the PHONES OUTPUT.
- You can connect another audio device to the AUX IN using standard RCA cables.

See the included assembly poster for further instructions on setting up the E-PRO LIVE Kit and connecting it to the RBM-20 module.

## IMPORTANT:

- Always turn down your volume level(s) to zero before plugging or unplugging your cables from your triggers or the module.
- The RBM-20 module may be affected by static electricity. If this occurs, simply turn the module off and wait at least a few seconds before turning it on again.

## GETTING STARTED

Please read the following instructions to set up your RBM-20 module for its first use!

### RESETTING THE MODULE TO FACTORY DEFAULTS

If you ever need to return the module to its original default factory settings, press and hold the **EXIT** and **SAVE** buttons simultaneously while turning it on.

### CHECK FOR UPDATES

Since the initial release of this module, we may have released new firmware or sound ROM files.

To ensure your RBM-20 module has the latest sounds and software features, we recommend checking the Customer Support tab of [www.redboxsoundshop.com](http://www.redboxsoundshop.com) for available updates.

See the **UPDATING THE MODULE** chapter for more information.

## IMPORTANT NOTICE FOR EPC-14T PLASTIC RIDE CYMBAL USERS

The **Ride Cymbal Trigger Settings** are pre-set at the factory for **E-Classic Metal RIDE cymbals**. If you're using an **E-Classic Metal RIDE cymbal** you don't have to do anything.

However, if you're using an **EPC-14T Plastic RIDE cymbal**, please follow the steps below to optimize playability.

1. Press **TRIG EDIT** to enter the main Trig. Edit Menu page.  
The first page shown should be **INP (F1)**.
2. Highlight the instrument at the top of the screen using the **CURSOR UP / DOWN** buttons then use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to change it to RideBell.
3. Use **CURSOR UP / DOWN** to move through the menu items and select InputType.
4. Use the **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** and change **PIEZO** to **SWITCH**.
5. Press the **SAVE** button to save this setting.
6. Press **KIT SELECT** to continue playing.

```
Input: RideBell
Sensitivity: 85
Function: TRIGGER
InputType: PIEZO
INP TRIG CURV MODE
```

```
Input: RideBell
Sensitivity: 85
Function: TRIGGER
InputType: SWITCH
INP TRIG CURV MODE
```

## DEACTIVATE WRITE PROTECTION

Out of the box, the RBM-20 module is write-protected, so you will be unable to save any changes you make to the Kits, Instruments, Sequences, etc.

To turn write protection off:

1. Press **UTILITIES**.
2. Press **SYS (F4)**.
3. Press **O/S (F3)**.
4. Press **MEM (F4)**.
5. Press **DEC- / INV+** or move the **VALUE / TEMPO DIAL** counterclockwise until the "WriteProt" field says "OFF."
6. Press **KIT SELECT** to return to the main page.

Utilities:General

```
Tempo : PATTERN
Output : MAIN&AUX
Acc Pitch : A=440Hz
Contrast : 60
CLK MIDI TRIG SYS
```

Utilities:O/S

```
Trig OS : V1.00
Sound ROM : V1.00
Sound OS : V1.00
```

SYSX INIT O/S MEM

Utilities:Memory

```
Memory : 99% FREE
WriteProt : OFF
```

SYSX INIT O/S MEM

## THE BASICS

This section of the manual outlines the basic features and concepts of the RBM-20.

Each section below refers to another part of this manual that will explain the features in greater depth.

## NAVIGATING MENUS & ADJUSTING SETTINGS


We designed the RBM-20's user interface to be as simple and as easy to use as possible.

- **KIT SELECT** – Press this button to select the Main Screen, where you can select the current Kit. (From this page, you can press **CURSER DOWN/KIT CONFIG** to enter the **KIT CONFIG Screen**, where you can adjust the overall Kit volume level, MIDI Program Change settings, or restore the current Kit's factory settings.)
- **UTILITIES** – Press this button to enter the UTILITIES Menu, where you can adjust click and MIDI settings, update or reset the module, and more. You can navigate the menus and adjust settings and parameters shown on the module's LCD with the following controls:
  - **TRIG EDIT** – Press this button to adjust sensitivity, crosstalk, thresholds, velocity curves, and other settings for the triggers.
  - **DRUM/LAYER or EDIT ACCOMP** – Press one of these buttons to reassign the sound for a trigger or to edit the sound of the Accompaniment track. You can also adjust other settings such as effects, velocity-related parameters, MIDI settings, and more.
  - **F-BUTTONS** – Pressing the **F1, F2, F3, and F4** buttons will select whatever "tab" is displayed above it on the LCD.
  - **DEC- / INC+** – Press the **DEC- / INC+** buttons to adjust the selected menu item (usually highlighted) one increment at a time. These buttons are better for more precise adjustment of settings than the **VALUE / TEMPO DIAL**.
  - **CURSOR UP / DOWN** – Press either of these buttons to move up or down through the menu on the screen. (Pressing the **CURSOR DOWN/KIT CONFIG** button while on the Main Screen will call up the **KIT CONFIG** screen where you can adjust the volume and MIDI settings of the current Kit.)
  - **VALUE / TEMPO DIAL** – Turn the wheel clockwise or counterclockwise to adjust the selected menu item (usually highlighted). This allows for quick adjustment of settings and parameters – the faster you turn the wheel, the faster it will scroll through the options.
  - **SEQ/SONG** – Press this button to enter the sequencer, where you can select a Sequence to play and adjust overall settings for the module's sequencer.
  - **EXIT** – Press this to return to the previous menu.

See the **TOP PANEL FEATURES** chapter for more information about these and other controls.

## KITS

The RBM-20 module includes 100 Preset Kits and 100 empty User Kits. A Kit is a set of sounds that you can select in the module that will be triggered by your drums when you play them. The Preset Kits come preprogrammed so you can start playing with premium sounds right away. The empty User Kits are for you to create your own by assigning individual sounds to each trigger in the Kit. Furthermore, you can save over the Preset Kits in user memory, allowing for even more creative space. (The defaults can be easily restored by reinitializing the module).



**To select a Kit, simply press KIT SELECT to enter the Main Screen, then use the DEC- / INC+ buttons or VALUE / TEMPO DIAL to select a new Kit number.**

For more information on selecting and editing Kits, see the KITS, VOICES, ACCOMPANIMENT & INSTRUMENTS chapter.

Important: At any given time, the RBM-20 module has a Kit selected and a Sequence selected. If you change the Sequence, this will change your current Kit to the one that is associated with that Sequence. If you change the Kit, this will NOT change the current Sequence. However, if you then play the current Sequence, the chords or “hit groups” may sound unusual. In this case, we recommend muting Layer B of that Kit’s Accompaniment (see EDITING VOICE & ACCOMPANIMENT PARAMETERS for more information) or muting the Accompaniment altogether by pressing MUTE ACCOMP.

## VOICES: LAYERS & INSTRUMENTS

Whenever you strike a trigger on your electronic drum set (e.g., a cymbal, a drum pad, etc.), it will trigger a Voice in the module. A Voice is the sound assigned to that trigger. Each Voice consists of two Layers, and each Layer has its own Instrument (a drum sound such as a tom, snare, hi-hat, etc.) which can be selected or edited.




We created the dual-layer feature in the RBM-20 so you can play with more powerful composite and layered sounds and timbres using your electronic drum kit. You can make subtle or dramatic changes to the sound of your Kits by changing the Instruments in each Layer. Furthermore, you can adjust certain parameters of the drum Voices (e.g., tuning, velocity, reverb, panning, etc.) in the module.

For more information on selecting and editing Voices, see the KITS, VOICES, ACCOMPANIMENT & INSTRUMENTS chapter.

## VOLUME


You may have noticed that there are several ways to adjust the volume of your performance when using the RBM-20. You can:



- **Adjust the levels of the Voices in the Kit:** Press KIT SELECT to enter the main screen then DRUM / LAYER. Press INST (F1) and select the Voice to edit (top of the LCD) with the DEC- / INC+ buttons or VALUE / TEMPO DIAL (or by striking the trigger with PAD ID on). Press LVL (F2) to enter the Level page. (Remember that each Voice has two Layers, A and B, which you can toggle between by pressing the DRUM/LAYER button.)



- **Adjust the level of the entire Kit:** Press KIT SELECT to enter the main screen then **CURSER DOWN/KIT CONFIG** to enter the **KIT CONFIG Screen**, where you can set the overall Kit level.



- Adjust the levels of drum sounds with the **MIXER**:  
Slide the faders on the module's MIXER.  
Use the **A/B SELECT** button to toggle between the two banks of sounds.

Please note the module's trigger sensitivity, threshold, velocity curve settings can also affect the dynamics of your performance. See the TRIG. EDIT MENU chapter for more information on adjusting these other settings.

## SEQUENCES

The RBM-20's built-in sequencer lets you record, overdub, edit, play back, and loop Sequences (drum patterns). You can adjust settings like the tempo, time signature, and quantization for a Sequence.

**To access the sequencer, press the module's SEQ / SONG button And navigate the menus or adjust the settings accordingly.**

For more information on using the sequencer, see the **SEQUENCES** chapter.

```
Seq#00: Indie Rock 00
Tempo : 95 BPM
Time Sig : 4/4
#Bars : 26
Loop : OFF
REC EDIT CLIK QUAN
```

**Important:** At any given time, the RBM-20 module has a Kit selected and a Sequence selected. If you change the Sequence, this will change your current Kit to the one that is associated with that Sequence. If you change the Kit, this will NOT change the current Sequence. However, if you then play the current Sequence, the chords or "hit groups" may sound unusual. In this case, we recommend muting Layer B of that Kit's Accompaniment (see **EDITING VOICE & ACCOMPANIMENT PARAMETERS** for more information) or muting the Accompaniment altogether by pressing **MUTE ACCOMP.**

## STORING DATA

The RBM-20 module can store the information you enter for use in future sessions. This includes Kits you edit or record, Sequences you edit or record, Instrument or Kit parameters, and more. Furthermore, while there are several slots for User Kits and Sequences, you can also save over the Presets (the first 100 Kits or the first 75 Sequences).

**To store a Kit, Instrument, or Sequence, press the KIT SELECT or SEQ/SONG button (respectively) to select the item you want to store, then press the SAVE button.** (If you are storing a Kit or Instrument, you will be asked to specify which.)

Use the **CURSOR UP / DOWN** buttons and **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to select the "From" Kit or /sequence (the one you want to save) and the "To" Kit or /sequence (where you want to save it to).

```
Save/Copy
Please
Select
DRUM KIT INSTRMENT
```

```
Save Kit
From: 00 1Up 2Down
↓
To: 101 User
NAME COPY SAVE
```

For more information on using storing data, see the **STORING & COPYING DATA** chapter.


## UTILITIES

The **UTILITIES** Menu lets you control global settings such as the output routing and trigger sensitivity as well as click, MIDI, and tempo settings. You can also transmit SysEx data in this menu as well as re-initialize the RBM-20 (i.e., return it to its factory settings). To access the UTILITIES Menu, press the module's UTILITIES Button and navigate the menus or adjust the settings accordingly. For more information, see the UTILITIES MENU chapter.

```

Utilities:General
Tempo : PATTERN
Output : MAIN&AUX
Acc Pitch : A=440Hz
Contrast : 60
CLK MIDI TRIG SYS
    
```

## REAR PANEL FEATURES



- 1. POWER SWITCH** – Turns the module on and off.
- 2. POWER IN** – Connect the included AC adapter to this input, then connect the adapter to a power source.
- 3. MAIN OUT** – Use 1/4" TS cables to connect these outputs to an amplifier or speaker system. The volume of these outputs is controlled by the **VOLUME** knob on the top panel.
- 4. AUX OUT** – Use a 1/4" TS cables to connect these outputs to a monitor system or recording device. The **AUX OUT** signal can be set to be identical to or independent of the MAIN OUT signal.
- 5. AUX IN** – Connect an external sound source, such as a CD player, to these inputs using a stereo pair of RCA cables.
- 6. USB** – Use a standard USB cable to connect the module to your computer via this USB port.  
This connection allows the module to send MIDI messages via USB to an external drum software module. You can also transmit SysEx files over this connection.
- 7. MIDI IN** – Use a standard five-pin MIDI cable to connect this input to the MIDI OUT of an external MIDI device.
- 8. MIDI OUT** – Use a standard five-pin MIDI cable to connect this output to the MIDI IN of an external MIDI device.
- 9. TRIGGER INPUTS** – Connect the triggers of your drum kit to the appropriate inputs here. Please note that dual-zone pads or cymbals (e.g., a drum with head and rim triggers or a cymbal with bow and bell sounds) will require TRS cables to trigger both zones.


**WARNING:**  
Use only the included Pearl Redbox power supply with the RBM-20 module.

**IMPORTANT:**  
Always turn down your volume level(s) to zero before plugging or unplugging your cables from your triggers or the module.

**Note:**  
The module's HI-HAT CONTROL TRIGGER INPUT does not support keyboard-style expression pedals.



## TOP PANEL FEATURES



1. **VOLUME** – Adjusts the volume level of the MAIN OUT.
2. **PHONES** – Adjusts the volume level of the PHONES OUTPUT on the module's front panel. The PHONES volume is independent of the module's VOLUME.
3. **PHONES OUTPUT** – Connect your 1/4" headphones to this output. You can adjust the volume of this output with the PHONES volume knob on the module's top panel.
4. **MIXER** – Slide these faders to adjust the levels for the different groups of drum sounds. Each fader controls a drum sound in each bank. The current bank (A or B) is determined by the A/B SELECT button.
5. **A/B SELECT** – Toggles between Banks A and B, determining which bank of triggers the MIXER's faders are affecting. An LED indicates the current bank. When neither LED is lit, these faders are disabled.
6. **CLICK ON / OFF** – Turns the **CLICK** on or off. You can adjust the click volume with the fader directly underneath this button (when **A/B SELECT** is set to Bank B).
7. **LCD** – Displays system menus, parameters, and other settings as you use the RBM-20.
8. **F-BUTTONS (1-4)** – These buttons allow you to navigate the menus shown in the LCD. Press an F-BUTTON to select the "virtual" button or tab shown above it in the LCD
9. **CURSOR UP / DOWN** – Use these buttons to move (vertically) through the available parameters shown in menus in the LCD.  
Note: Pressing **CURSER DOWN/KIT CONFIG** from the Main Screen allows you to adjust overall parameters for the current Kit.
10. **VALUE / TEMPO DIAL** – Turn this wheel to increase and decrease values and settings shown in the LCD.
11. **DEC- / INC+** – Use these buttons to decrease and increase values and settings shown in the LCD. These may be easier to use than the **VALUE / TEMPO DIAL** when making incremental adjustments to your parameters.
12. **EXIT** – Press this button to return to the previous menu shown in the LCD.
13. **KIT SELECT** – Returns the LCD to the Main Screen. From here, you can select the current Kit with the **VALUE / TEMPO DIAL** or **DEC- / INC+** buttons.
14. **UTILITIES** – Enters the **UTILITIES** Menu, which allows you to set certain "global" parameters that affect the RBM-20's overall operation (e.g., tempo, MIDI, output routing, trigger sensitivity, etc.). (See the Reference Manual for more information.)
15. **TRIG EDIT** – Allows you to adjust parameters related to triggering. Customizing these parameters changes the feel and responsiveness of the Kit.  
Note: Changes to these parameters will affect ALL Kits.
16. **PAD ID** – Turns **PAD ID** on or off. When **PAD ID** is on, striking a trigger automatically selects it for editing. Alternatively, you can select a trigger by highlighting the trigger field in the LCD with the **CURSOR UP / DOWN** buttons then using the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL**.
17. **DRUM/LAYER** – Press this button then **INST (F1)** to edit the Instrument assigned to a trigger input. While editing, pressing it toggles between the two Layers of the trigger. The current Layer (A or B) will be highlighted on the top-right corner of the LCD.

**18. EDIT ACCOMP** – Press this button to adjust the settings for your Accompaniment.

The adjustable parameters will be shown in the LCD.

**19. PREVIEW** – Press this velocity-sensitive button to preview the sound of the current trigger. This can be useful when programming the RBM-20 if it is not connected to your drum kit, if it is not convenient to strike the pads, etc.

**20. SAVE** – Press this button to save changes made to the current Kit, Sequence, trigger settings, or global settings. Use the **VALUE / TEMPO DIAL** or **DEC- / INC+** buttons to select a destination where the current Kit or Sequence will be stored. When saving a Kit, its Instruments and all its parameters will also be stored. When saving a Sequence, it will remember its corresponding Kit and Accompaniment.


**21. SEQ/SONG** – Press this button to access the module's Sequencer where you can create and edit drum and accompaniment patterns.

**22. MUTE DRUMS** – Press this button to mute the drum track of a Sequence.

**23. MUTE ACCOMP** – Press this button to mute the Accompaniment track of a Sequence.

**24. STOP** – Stops playback of the current Sequence. Hold down **STOP** and turn the **VALUE / TEMPO DIAL** to “scrub” forwards and backwards through the Sequence. Hold down **STOP** and press **DEC- / INC+** to “step” forwards or backwards through each “event” in the Sequence. While navigating the Sequence in these ways, you will hear the Sequence play as you move through it.

**25. PLAY**  – Plays the current Sequence. You can also hold down **STOP** and press this button to move back to the previous bar in the Sequence.

**26. RECORD**  – Records a new Sequence. You can also hold down **STOP** and press this button to move to the next bar in the Sequence.

**27. TAP TEMPO**  – Tap this button at the desired rate to enter a new tempo for the Sequence. You can also change the tempo by holding down the **TAP TEMPO** button and using the **VALUE / TEMPO** or **DEC- / INC+** buttons.

## KITS, VOICES, ACCOMPANIMENT & INSTRUMENTS

The RBM-20 Module has 100 Preset Kits and 100 User Kits, which you can select from the Main Screen. Each Kit is a collection of Voices – or drum sounds – that are assigned to each **TRIGGER INPUT** on the RBM-20 module's rear panel. When a trigger connected to that input is struck, that Voice will sound.

Each Voice consists of two Layers, each with its own Instrument. Both Layers sound together, helping to create powerful composite and layered sounds and timbres for a more dynamic performance.

You can change the sound of your performance by selecting different Kits or by editing the Kits by changing the Instruments that make up each Voice. You can also edit various parameters of each Instrument themselves (e.g., level, panning, decay, reverb, etc.) in each Kit.

**IMPORTANT:** At any given time, the RBM-20 module has a Kit selected and a Sequence selected. If you change the Sequence, this will change your current Kit to the one that is associated with that Sequence. If you change the Kit, this will NOT change the current Sequence. However, if you then play the current Sequence, the chords or “hit groups” may sound unusual. In this case, we recommend muting Layer B of that Kit's Accompaniment (see **EDITING VOICE & ACCOMPANIMENT PARAMETERS** for more information) or muting the Accompaniment altogether by pressing **MUTE ACCOMP**.

## SELECTING A KIT

1. Press the **KIT SELECT** button to bring up the Main Screen.

2. Use the **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** to select a Kit. The Kit number, name, and graphic will change as you move through the different Kits.

3. Hit the triggers to try out the sounds of the Kit. To make quick adjustments to the volume of different parts of the Kit, slide the faders of the **MIXER**. (Use **A/B SELECT** to toggle between Banks A and B to access all available triggers.) Note that the levels you set with the **MIXER** will be lost when you switch the module off.

To set levels that can be recalled with the Kit, set the “Level” parameters for the individual triggers (see **EDITING VOICE & ACCOMPANIMENT PARAMETERS** in this chapter) and/or the entire Kit (see **KIT SELECT SETUP** in this chapter).



## EDITING INSTRUMENTS IN A KIT

1. Press **KIT SELECT** to go to the Main Screen.

2. Press **DRUM/LAYER**. The top of the screen will show the number and name of the Kit whose Instruments (drum voices) you will be editing.

3. Select **INST (F1)**. The new screen will show:

a. the trigger Voice you are editing (the Kit number and name of the Voice will be shown)

b. the Layer (each Voice consists of two layers, each with its own Instrument)

c. the Category (the type or “class” of drum sound currently assigned to that Layer)

d. the Instrument (the drum sound for that Layer)

4. Select the Voice whose Instrument you want to change by pressing **PAD ID** then striking the desired trigger.

Alternatively, you can highlight the Voice (next to the Kit number) using the **CURSOR UP / DOWN** buttons to highlight it and use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to change it.

5. Select which Layer of that Voice you will edit by pressing **DRUM/LAYER**. It will toggle between Layer A and B.

6. Select the Category you want to assign to that Voice by pressing **CURSOR UP / DOWN** to highlight the Category field, then use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to change it.

7. Select the Instrument for that Layer by pressing **CURSOR UP / DOWN** to highlight the Instrument field, then use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to change it. To hear the currently selected sound, strike the corresponding trigger or press **PREVIEW** on the module.



**NOTE:** The available instruments for the hi-hat and Ride cymbal categories are pro-defined setsof sounds designed to work together (e.g. the hi-hat can produceopen, closed, “chick”, or splash sounds) You can assign any category or instrument you like for the hi-hat and Ride cymbal triggers, but because other instruments are designed to work differently, the results will vary.

## EDITING ACCOMPANIMENT IN A KIT

1. When you are in the Kit whose Accompaniment you want to edit, press **EDIT ACCOMP**. The screen will show:

a. the number of the Kit whose Accompaniment you will be editing

b. the Layer (the Accompaniment consists of two layers, each with its own Instrument)

c. the Category (the type or “class” of sound currently assigned to that Layer)

d. the Instrument (the sound for that Layer)

2. Select which Layer of the Accompaniment you will edit by pressing **DRUM/LAYER**

It will toggle between Layer A and B.

3. Select the Category you want to assign to that Voice by pressing **CURSOR UP / DOWN** to highlight the Category field, then use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to change it.

4. Select the Instrument for that Layer by pressing **CURSOR UP / DOWN** to highlight the Instrument field, then use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to change it. To hear the currently selected sound, strike the corresponding trigger or press **PREVIEW** on the module.



### Useful information about Accompaniment:

The Accompaniment track includes the bass line and other synthesizer sounds that you hear when the module is playing a Sequence. The drum track and Accompaniment track play simultaneously, and you can mute either of the tracks as they play with the **MUTE DRUMS** or **MUTE ACCOMP** buttons.

Just as each drum Instrument of a Kit belongs to a Category (e.g., **KICKS**, **SNARES**, **LATIN PERC**, etc.)

Accompaniment Instruments are also grouped into several Categories: **BASS**, **SYN BASS**, **FX**, and **HIT GROUPS**.

Also, just like drum Voices, the Accompaniment has two Layers of Instruments. Layer A is usually the bass line. Layer B is often something different – another melodic line, chords, or “hits.”

Instrument changes within or between the **BASS** and **SYN BASS**

Categories may sometimes be desirable – the bass will have a different tone or quality while the bass line itself (the notes you hear) remains the same. However, if you edit the Instruments in the FX or HIT GROUPS Categories, it may dramatically change the way a Sequence sounds if it uses that Kit.

In this case, we recommend muting that Layer of that Kit's Accompaniment (see **EDITING VOICE & ACCOMPANIMENT PARAMETERS** for more information) or muting the Accompaniment altogether by pressing **MUTE ACCOMP.**

### EDITING VOICE & ACCOMPANIMENT PARAMETERS

While editing your Kits by changing the Instruments in a drum Voice or the Accompaniment, you can also edit various parameters that affect each Layer and, therefore, the Instrument on that Layer. You can do this for the drum Voices or the Accompaniment, though some parameters below may only be editable for one of these.

1. Press **KIT SELECT** to go to the Main Screen.
2. Press **DRUM/LAYER** to edit drum Voice parameters or **EDIT ACCOMP** to edit Accompaniment parameters. The top of the screen will show the number and name of the Kit whose Instruments (drum Voices or Accompaniment) you will be editing.
3. Select **INST (F1)**. The new screen will show:
  - a. the trigger Voice you are editing (the Kit number and name of the Voice will be shown). If you are editing the Accompaniment, this will read "Accomp."
  - b. the Layer (each trigger sound or Accompaniment track consists of two Layers, each with its own Instrument)
  - c. the Category (the type or "class" of drum sound or Accompaniment currently assigned to that Layer)
  - d. the Instrument (the drum or Accompaniment sound for that Layer)

**4. If you are editing a Voice**, select the Voice whose Instrument you want to change by pressing **PAD ID** then striking the desired trigger. Alternatively, you can highlight the Voice (next to the Kit number) using the **CURSOR UP / DOWN** buttons to highlight it and use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to change it. (This step is not necessary when editing Accompaniment.)

Note: You can also change the current Voice in this fashion in any of the subsequent menus. You can also toggle between Layers by pressing **DRUM/LAYER** whenever the "Layer: A B" selector is shown on the upper right corner of the LCD.

**5. Select any of the options at the bottom of the LCD using the F-BUTTONS.**

Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+** or the **VALUE / TEMPO DIAL** to adjust the settings.

**Note:**  
The RBM-20 will retain any changes you make to Instruments or parameters as you move between the various kits.



• **LVL (F2, 1st page):**

• **Level:** The volume level for the selected Layer (01-99 or "OFF").


• **Pan:** The panning for the selected Layer ("L50" to "MID" to "R50").

• **Attack:** The volume level of the initial attack of the note (00-99).

This parameter is only available when editing Accompaniment.

• **Decay:** How long the sound can be heard before decaying to silence (00-99 or "OFF").

Note: Setting this parameter to "OFF" disables the Decay parameter and the sound will be heard for its entire duration with no "shaping."



• **FX (F3, 1st page):**

• **Reverb:** The amount of reverb on the Voice (00-99).

• **Effects:** The Voice volume level sent to the RBM-20's effects processor (00-99).

• **EQ/Comp:** This sends the Voice to the RBM-20's equalizer and compressor ("ON" or "OFF").




• **TONE (F1, 2nd page):**

• **Semitone:** Tunes the Instrument ±12 semitones.

• **Fine Tune:** Tunes the Instrument ±50 cents.

• **Filter:** The cutoff frequency for the type of filter (see below) (00-99).

• **Type:** The type of filter ("LOPASS" or "HIPASS").



• **DYN (F2, 2nd page):**


• **Vel>Decay:** The velocity of a note will control the decay time of its sound (±00-99). With a positive value, higher-velocity notes will have a longer decay time. With a negative value, higher-velocity notes will have a shorter decay time.

• **Vel>Filtr:** The velocity of a note will control the filter cutoff (±00-99).

• **Vel>Level:** This lets you set how velocity-sensitive the Instrument is (00-99). The higher the setting, the greater the dynamic range you'll have while playing. At "00," there will be no dynamic variation at all.

• **Vel>Pitch:** The velocity with which you strike the trigger will control the sound's pitch (±00-99).

With a positive value, stronger hits will increase the pitch. With a negative value, stronger hits will decrease the pitch. (This parameter is not available for anything in the **BASS** or **SYN BASS** Categories when editing the Accompaniment.)



• **OTHR (F3, 2nd page):**

• **Output:** The output through which the Voice or Accompaniment will be sent. When "MAIN" is selected, the Voice or Accompaniment will be sent out of the **MAIN OUT**. When "AUX" is selected, the Voice or Accompaniment will be sent out of the **AUX OUT**.

**Note:** If your **UTILITIES** Menu setting for the "Output" is set to "Main->Aux," the "AUX" option here will show up as "AUX (N/A)." This is because the **AUX OUT** signal is "mirroring" the **MAIN OUT** signal. See the **GENERAL** menu part of the **UTILITIES MENU** section for more information.

• **Priority: How high the Voice's or Accompaniment's "polyphony priority" is** – "LOW," "MEDIUM," or "HIGH." "Polyphony" is the simultaneous sounding of Instruments (e.g., if you strike multiple triggers at the same time, like the hi-hat, snare, and kick drum). The RBM-20 has **64-voice polyphony**, meaning up to 64 voices can sound at the same time. After exceeding that limit, Voices or Accompaniment with lower polyphony priority may be silenced so the ones with higher priority can sound.

• **MuteGroup:** The MuteGroup the Voice is assigned to, if any (01-09 or "OFF"). When two or more triggers are assigned to a MuteGroup, a Voice that is currently sounding will be silenced when another Voice from that MuteGroup begins. There are nine available MuteGroups.

**Example:** If your "Kick1" (kick drum) and "SnrHd" (snare drum head) are assigned to the same MuteGroup, the decay of your snare drum will be cut off when you hit the kick drum and vice versa.

• **Playback:** Indicates whether repeated strikes of the same trigger will be considered polyphonic (**POLY**) or monophonic (**MONO**). When set to "POLY" (the default), successive strikes of the same trigger will be allowed to sound simultaneously as polyphony (see "Priority" above). When set to "MONO," successive strikes of the same trigger will silence previous ones.



**Note:** The MuteGroup function is especially useful for setting up multiple sounds shared by the same instruments, like "open" vs. "closed" triangle sounds or struck vs. stroked güiros.

**Note:** The default Playback setting is POLY, which is more natural for acoustic drums. MONO is a useful setting for synth drums or for emulating older drum machines.

**EDITING MIDI PARAMETERS**

This page allows you to edit various MIDI-related settings for each trigger. To edit them,

1. Press **KIT SELECT** to go to the Main Screen.
2. Press **DRUM/LAYER**. The top of the screen will show the number and name of the Kit whose Instruments (drum voices) you will be editing.
3. Select **MIDI (F2)**. The top of the new screen will show the trigger Voice you are editing. You can select another trigger by pressing **PAD ID** then striking the desired trigger. Alternatively, you can highlight the Voice (next to the Kit number) using the **CURSOR UP / DOWN** buttons to highlight it and use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to change it.

**Note:** You can also change the current Voice in this fashion in any of the subsequent menus.

4. When you have selected the Voice you want to edit, select either of the options at the bottom of the LCD using the **F-BUTTONS**. Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+** or the **VALUE / TEMPO DIAL** to adjust the settings:



## MIDI

- **MIDI Chan:** The MIDI channel over which the trigger will transmit MIDI messages.
- **MIDI Note:** The MIDI note that will be transmitted. The number is the MIDI Note number; the corresponding musical note is shown next to it. (Note: The MIDI note for the hi-hat and ride cymbals is fixed and can not be reassigned.)
- **Gate Time:** The duration of the note sent from the trigger when struck. The available range is from 00-99 ms, then note values (1/32, 1/16, 1/8, 1/4, and 1/2 – with regular and triplet divisions for each value), or “OFF.”
- **Note Off:** How the MIDI Note Off message is sent. When “NOT SENT” is selected, a MIDI Note Off will not be transmitted. When “SENT” is selected, a MIDI Note Off will be sent after the length of time specified by the Gate Time (above). When “ALTERNATE” is selected, striking a trigger once will cause it to send its MIDI Note; striking it a second time will cause it to send a MIDI Note Off.

**b. CHORD / ARP:** Select “OFF,” “CHORD,” or “ARPEGGIO.” (Note: The CHORD / ARP function is not available for the hi-hat and ride cymbals.)

- **OFF:** The trigger will transmit only the MIDI note assigned to it.
- **CHORD:** The trigger will transmit up to four MIDI notes simultaneously whenever it is struck. You can select the additional three notes here. The number is the MIDI Note number; the corresponding musical note is shown next to it in parentheses.
- **ARPEGGIO:** The trigger will transmit up to four MIDI notes but will “rotate” through them with each strike (e.g., the first time the trigger is struck, it will send its first MIDI note; the next time, it will send Note #2; the next time, it will send Note #3). You can select the three additional notes here. The number is the MIDI Note number; the corresponding musical note is shown next to it in parentheses.

## EDITING EFFECTS PARAMETERS

On this page, you can apply a variety of effects such as reverb, chorus, or delay to the entire Kit.

1. Press **KIT SELECT** to go to the Main Screen.
2. Press **DRUM/LAYER**. The top of the screen will show the number and name of the Kit whose effects you will be editing.
3. Select **FX (F4)**.
4. Select any of the options at the bottom of the LCD using the F-BUTTONS.

Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+ or the VALUE / TEMPO DIAL** to adjust the settings:

### a. RVB (reverb)



- **Type:** The kind of reverb applied (most often, types of reverb are named after the kind of room whose reverb is being emulated). To disable effects on the Kit, select “OFF.”
- **Size:** The size of the virtual “room” as designated by the reverb Type.
- **Color:** The amount of high-frequency dampening of the reverb, which affects its tone.
- **Level:** The level of the reverb.

### b. FX (other effects)

• **Type:** The kind of effect applied. To disable effects on the Kit, select “OFF.” The effects –and their editable parameters – are as follows:

- **FLANGER:** Flanging is a kind of phasing or phase-shifting. The RBM-20’s flangers have the same editable parameters.
  - **Mono Flanger:** Traditional flanging effect.
  - **Stereo Flanger:** Flanger with a simulated stereo effect, creating a “wider” sound.
  - **XOver Flanger:** The flanging effect “moves” around the stereo field.
- **Rate:** The speed at which the sound will “flange.”
- **Depth:** How much of the delayed (or phase-shifted) signal is added to the original.

- **Feedback:** How much of the flanging signal will be routed back into the flanger again, which intensifies the effect.
- **Level:** The volume level of the flanging signal.



**CHORUS:** A chorus effect is produced by adding a slightly delayed and slightly pitchshifted “wet” signal to the original (“dry”) signal, producing a sound with a depth similar to that of a string section or choir. The RBM-20’s chorus effects have the same editable parameters.

**Mono Chorus 1:** Traditional chorus effect.

**Mono Chorus 2:** A variation of the traditional chorus effect.

**Stereo Chorus:** Chorus with a simulated stereo effect, creating a “wider” sound.

**XOver Chorus:** The chorus effect “moves” around the stereo field.

**Rate:** The speed of the modulation of the chorus (or how much the signal is delayed).

**Depth:** How much the chorus’s delay varies.

**Feedback:** How much of the delayed signal will be routed back into the processor again, which creates a thicker chorus effect.

**Level:** The volume level of the chorus signal.

**VIBRATO:** Vibrato is produced by causing the pitch of a note to “waver” slightly back and forth, creating a subtle pulsing effect. This effect is often created by players of string instruments and horns. The RBM-20’s vibrato effects have the same editable parameters.

**Mono Vibrato:** Traditional vibrato effect.

**Vibrato:** Vibrato with a simulated stereo effect, creating a “wider” sound.

**Rate:** The speed of the vibrato (how quickly the pitch wavers).

**Depth:** How much the pitch wavers from the center/original pitch.

**Level:** The volume level of the vibrato.

**DELAYS:** A delay effect is a kind of echo, which varies depending on the size of the room it emulates and the rate, volume, and decay of the echo. The RBM-20’s delay effects have some common parameters with some notable differences.

**Mono Doubler:** A very quick delay that creates a “double-hit” effect.

**Doubler:** A very quick delay that creates a “double-hit” effect in a stereo field.

**Delay:** The speed of the delay/echo.

**Level:** The volume level of the delayed signal.

**Mono Slapback:** A quick – almost immediate – delay.

**Slapback:** Quick delay with a simulated stereo effect, creating a “wider” sound.

**Delay:** The speed of the delay/echo.

**Level:** The volume level of the delayed signal.

**Mono Delay:** A traditional delay effect.

**Delay:** The speed of the delay/echo.

**Feedback:** How much of the echo will be routed back into the processor again, which creates a longer-lasting, intensified echo effect.

Kit000:1Up 2Down

```
Type : Mono Chorus 1
Rate : 36   Depth : 58
Feedback : 0%
Level : 99
RUB  FX  COMP  EQ
```

Kit000:1Up 2Down

```
Type : Vibrato
Rate : 43   Depth : 36
Level : 99
RUB  FX  COMP  EQ
```

Kit000:1Up 2Down

```
Type : Doubler
Delay : 50ms
Level : 99
RUB  FX  COMP  EQ
```

Kit000:1Up 2Down

```
Type : Slapback
Delay : 140ms
Level : 99
RUB  FX  COMP  EQ
```

Kit000:1Up 2Down

```
Type : Mono delay
Delay : 300ms
Feedback : 55%
Damp : 00   Level : 99
RUB  FX  COMP  EQ
```



**Damp (dampening):** The amount of low- and high-frequency dampening of the echo. At negative values, the sound of the echo gets progressively duller, which is the most “natural” echo effect. This is also useful for simulating tape echo. At positive values, the sound of the echo gets progressively thinner.

**Level:** The volume level of the delayed signal.

**Delay:** A traditional delay with two independent delay lines.

**LDly / RDly (left/right delay):** The speed of the delay/echo. This can be set independently for the left and right channels to create an even wider, more varied sound.

**LFbk / RFbk (left/right feedback):** How much of the echo will be routed back into the processor again, which creates a longer-lasting, intensified echo effect. This can be set independently for the left and right channels to create an even wider, more varied sound.

**Damp (damping):** The amount of low- and high-frequency dampening of the echo. At negative values, the sound of the echo gets progressively duller. At positive values, the sound of the echo gets progressively thinner.

**Level:** The volume level of the delayed signal.

**XOver Delay:** This delay has a stereo effect. The echo pans around the stereo field.

**LDly / RDly (left/right delay):** The speed of the delay/echo. This can be set differently for the left and right channels to create an even wider, more varied sound.

**Feedback:** How much of the echo will be routed back into the processor again, which creates a longer-lasting, intensified echo effect.

**Damp (damping):** The amount of low- and high-frequency dampening of the echo. At negative values, the sound of the echo gets progressively duller. At positive values, the sound of the echo gets progressively thinner.

**Level:** The volume level of the delayed signal.

**PingPong:** This delay has a stereo effect, but instead of echoing in both left and right channels simultaneously, the echo alternates between them.

**Delay:** The speed of the delay/echo.

**Feedback:** How much of the echo will be routed back into the processor again, which creates a longer-lasting, intensified echo effect.

**Damp (damping):** The amount of low- and high-frequency dampening of the echo. At negative values, the sound of the echo gets progressively duller. At positive values, the sound of the echo gets progressively thinner.

**Level:** The volume level of the delayed signal.

```
Kit000:1Uf 2Down
Type : Delay
Delay L:800ms R:300ms
FdBck L:55% R:78%
Damp : 00 Level : 99
RUB FX COMP EQ
```

```
Kit000:1Uf 2Down
Type : XOver delay
Delay L:300ms R:600ms
Feedback : 71%
Damp : 00 Level : 99
RUB FX COMP EQ
```

```
Kit000:1Uf 2Down
Type : PingPong
Delay : 500ms
Feedback : 90%
Damp : 00 Level : 99
RUB FX COMP EQ
```

### c. COMP (compression)

- **Type:** The kind of compression applied. To disable the dynamic processor on the Kit, select "OFF."
- **Compress (compression):** The compression ratio applied to the signal from the Kit.
- **Out Level (output level):** The output level of the compressor. This is parameter is useful for boosting the Kit's signal if its volume has decreased due to the compression.

```
Kit000:1U# 2Down
  Type : Rok1
  Compress : 09
  Out Level : 03dB
RUB FX COMP EQ
```

### d. EQ (equalization)

- **LF Gain (low-frequency gain):** The amount of boost or cut of the low frequency band (as determined by the LF Freq setting).
- **LF Freq (low frequency):** The frequency the LF Gain will boost or cut.
- **HF Gain (high-frequency gain):** The amount of boost or cut of the high frequency band (as determined by the HF Freq setting).
- **HF Freq (high frequency):** The frequency the HF Gain will boost or cut.

```
Kit000:1U# 2Down
  LF Gain : 02dB
  LF Freq : 100Hz
  HF Gain : 05dB
  HF Freq : 2.7kHz
RUB FX COMP EQ
```

## KIT SELECT SETUP

While selecting Kits, you can enter the **KIT CONFIG** Screen to access a few useful parameters pertaining to the current Kit.

1. Press **KIT SELECT** to go to the Main Screen.
2. Use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to select a Kit.
3. Press **CURSOR DOWN/KIT CONFIG** to enter the **KIT CONFIG** Screen for that Kit.
4. Select any of the options at the bottom of the LCD using the **F-BUTTONS**. Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+ or the VALUE / TEMPO DIAL** to adjust the settings.

**Note:**  
The RBM-20 will retain any changes you make to the Instruments or parameters as you move between the various Kits.

- **MAIN (F1):**
  - **Kit Level:** The overall volume level for the Kit (00-99)
  - **Graphic:** The image used to identify the Kit on the main screen.
- **MIDI (F2):**
  - **MIDI Chan:** The MIDI channel over which the module will send out Program Change messages (01-16 or "OFF"). (When set to "OFF," the other parameters below will not be displayed.) You will need to set this properly when using the RBM-20 module to play sounds on another module.
  - **Ext Prog#:** The Program Change number the module will send out (00-99).
  - **MSB:** Sets the Most Significant Byte when using sounds on an external module that requires bank changes (00-127 or "OFF").
  - **LSB:** Sets the Least Significant Byte when using sounds on an external module that requires bank changes (00-127 or "OFF").

```
Kit:Main
Kit Level : 99
Graphic : AC ROCK
MAIN MIDI RESTORE
```

```
Kit:MIDI Prog Change
MIDI Chan : 01
Ext Prog# : 00
  MSB : OFF
  LSB : OFF
MAIN MIDI RESTORE
```

- **RESTORE (F3 or F4):**

- **Restore:** Returns the Kit to its original factory settings.


Any edits you made to its Instruments, Accompaniment, etc. will be discarded. To restore the original settings, press **(F1 or F2)**. To cancel, press **EXIT**.



## SEQUENCES

A Sequence is a recorded pattern stored in the RBM-20 module that includes drums and Accompaniment. The drum part of the Sequence includes the Kit sounds (Instruments) as well the recorded pattern itself.

The Accompaniment is the music that plays along with the drum part. Sequences can be recorded, edited, looped, and stored. You can also mute the drum part and/or Accompaniment while playing a Sequence.



To hear a demo Sequence, simply hold down **SEQ/SONG** and press **PLAY**.

Important: At any given time, the RBM-20 module has a Kit selected and a Sequence selected.

- If you change the Sequence, this will change your current Kit to the one that is associated with that Sequence.

- If you change the Kit, this will NOT change the current Sequence.

However, if you then play the current Sequence, the chords or “hit groups” may sound unusual. In this case, we recommend muting Layer B of that Kit’s Accompaniment (see **EDITING VOICE & ACCOMPANIMENT PARAMETERS** for more information) or muting the Accompaniment altogether by pressing **MUTE ACCOMP**.

**Note:** Whenever you edit a Sequence or make changes to any parameters, an “E” will appear in the upper-right corner of the main screen of the Sequencer to indicate this. In order to retain these settings for future sessions, you must store the Sequence (see **STORING SEQUENCES** under the **STORING & COPYING DATA** chapter).

## PLAYING SEQUENCES

1. Press **SEQ/SONG** to enter the main screen of the Sequencer.
2. Use the **CURSOR UP / DOWN** buttons to highlight the “Seq” field at the top of the LCD.

3. Use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to select a Sequence.

4. You can press **PLAY** to play the Sequence, or you can use the **CURSOR UP / DOWN** buttons to select settings to edit for that Sequence. Use the **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** to change the settings:

- **Tempo:** The speed (in BPM or beats per minute) of the sequence.

You can set the tempo here, or you can press the **TAP TEMPO** button several times at the desired tempo to enter a new one.

The range is 30 to 300 BPM.



**Note:** If the Tempo field of the **UTILITIES** Menu's main page is set to "**GLOBAL**," the letter "G" will be shown.


If the Clock In field of the **UTILITIES** Menu's MIDI page is set to "**RECEIVE**," the letter "E" will be shown.

- **Time Sig** (Time Signature): The time signature of the sequence. The first number indicates how many beats there are in a measure; the second number indicates the note value of those beats. (Example: "3/4" means one measure is three quarter notes long. "12/8" means one measure is twelve eighth notes long.)

- **#Bars:** The number of bars in the Sequence, which you can set from 1 to 99.

- **Loop:** You can set the Sequence to loop or to play only once.

5. Press **PLAY** to play the Sequence. A "**PLAY BUTTON**" will appear on the upper right-hand corner of the LCD. To mute the drums or Accompaniment in the Sequence, press the **MUTE DRUMS** or **MUTE ACCOMP** button, respectively. The upper right-hand corner of the LCD indicates whether the drums ("D") and Accompaniment ("A") are muted. When unmuted, the letter is highlighted. (This is a useful tool when you want to play your own drum patterns to the Accompaniment or vice versa.)



### RECORDING SEQUENCES

1. Press **SEQ/SONG** to enter the main screen of the Sequencer.

2. Press the **REC** tab (F1).

3. Use the **CURSOR UP / DOWN** buttons to select settings to edit for that Sequence. Use the **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** to change the settings:

- **Track:** The track of the Sequence over which you will be recording – "**DRUMS**" or "**ACCOMP**."

- **Rec Type:** How the performance will be recorded. When "**RECORD**" is selected, the performance you record will replace the recording on that Track of the Sequence. When "**OVERDUB**" is selected, the performance you record will be added to the existing recording on that Track of the Sequence.

- **Quantize:** The quantization level of the recording. When on, this function will "snap" all recorded notes to the nearest interval of that measure, which you select. (For instance, if you select "1/8," any notes you record that do not fall on an eighth-note pulse will be shifted automatically to the nearest one.) The range is 1/4 – 1/64 (regular or triplet) and "OFF."

- **Swing:** The amount of swing applied to the recording – 54%, 58%, 62%, or "OFF."

6. Press the module's **REC** button and record your performance.

7. When you are finished recording, press **STOP**.



### EDITING SEQUENCES (DRUMS)


The editing screen for a Sequence's drum part allows you to see a visual representation of the drum pattern.

1. Press **SEQ/SONG** to enter the main screen of the Sequencer.

2. Use the **CURSOR UP / DOWN** buttons to select the "Seq" field at the top of the LCD, then use the **VALUE UP / DOWN** buttons or the **VALUE / TEMPO DIAL** to select the Sequence you want to edit.

3. Press **REC** (F1). Use the **CURSOR UP / DOWN** buttons to select the "Track" field, then use the **VALUE UP / DOWN** buttons or the **VALUE / TEMPO DIAL** to select "DRUMS."

4. Press **EDIT** (F2). You will see a grid on the screen. The diamonds indicate triggered notes or "events"; the black diamond is the currently selected event. Each column represents an interval/subdivision of the bar. Each row of the grid represents a drum Voice:



- **K** = kick drum
- **S** = snare drum
- **HH** = hi-hat
- **T1** = 1st tom

- **T2** = 2nd tom
- **T3** = floor tom
- **C** = crash cymbal
- **R** = ride cymbal

- **A1** = Ride2 / Acc1 trigger
- **A2** = Acc2 trigger
- **A3** = Acc3 trigger
- **A4** = Acc4 trigger

- The numbered rows correspond to available MIDI note numbers.

5. You can use the following controls to edit your Sequence in this screen:

- **CURSOR UP / DOWN** scrolls up or down, allowing you to view other parts of the editing grid.
- You can move through the Sequence in several ways:
  - **by bar:** Press and hold **STOP** and press either **PLAY** or **RECORD** to step through the Sequence bar by bar.

- **by event:** Use **CURSOR < / >** (F3 and F4) or press and hold **STOP** and use the **DEC- / INC+** to step through the **Sequence** event by event. Each event will play as it is selected.

- **“Scrubbing”:** Press and hold **STOP** and turn the **VALUE / TEMPO DIAL** to move fluidly through the Sequence.

The Sequence will play back at the speed with which you rotate the **VALUE / TEMPO DIAL**.



- **DEC- / INC+** or the **VALUE / TEMPO DIAL** will either shift the event in time (earlier or later) or adjust its velocity (higher or lower), depending on the setting of the F2 button.

- **TIME / VELO (F2)** lets you toggle between two views of the editing grid. When **TIME** is selected, using the **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** will adjust the timing of the selected event, moving it forward or backward in the Sequence (the current “click” number will be shown in the upper right-hand corner of the LCD).

- When **VELO** is selected, using the **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** will adjust the velocity of the selected event, moving it higher or lower (the current velocity will be shown in the upper right-hand corner of the LCD).

- **DEL (F1)** will delete the selected event from the Sequence. A window will ask you to confirm this choice before deleting it – select **YES (F4)**, **NO (F3)**, or **TRAK (F1)**, which will delete the entire Sequence.

6. When you have finished making your edits, you can press **EXIT** or any button that will enter another screen (e.g., **KIT SELECT**, **UTILITIES**, etc.). Your edits will be retained in the Sequence for this session. If you want to save your changes for future sessions, though, you will need to store them (see **STORING & COPYING DATA** for more information).



### EDITING SEQUENCES (ACCOMPANIMENT)

The editing screen for a Sequence's Accompaniment is different from the one used to edit drums.

1. Press **SEQ/SONG** to enter the main screen of the Sequencer.
2. Use the **CURSOR UP / DOWN** buttons to select the “Seq” field at the top of the LCD, then use the **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** to select the Sequence you want to edit.

3. Press **REC (F1)**. Use the **CURSOR UP / DOWN** buttons to select the “Track” field, then use the **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** to select “**ACCOMP**”

4. Press **EDIT (F2)**. You will see a table of values. Each row represents a note or “event” in the Sequence. Each column represents the events' positions and parameters:

- **Bar / Beat / Clk \***: The position of that event in the Sequence by bar, beat (within that bar), and click (within that beat). As you move down the table, you move through the Sequence.
- **Note:** The MIDI note being sent. (See next page for an explanation of how the sequencer refers to MIDI note numbers.)
- **Velo:** The velocity of the note (1-127).
- **Dur:** The duration of the note, measured in clicks (1-9999).



BAR	BEAT	CLK	NOTE	VELO	DUR
002	01	24	E2	100	20
002	01	24	C#4	101	23
002	01	48	D2	85	25
002	01	48	D4	102	37

DEL EDIT <CURSOR>

**\* Note:**

A “click” is just a subdivision of a quarter note in the RBM-20's sequencer, which defines its resolution. The RBM-20's resolution is 96 PPQN (pulses per quarter note), meaning each quarter note contains 96 clicks. This is helpful to know while editing Sequences' Accompaniment tracks if you are trying to shift a note into a precise position within a beat

5. You can use the following controls to edit your Sequence in this screen:

- You can move through the Sequence in several ways:
  - **by bar:** Press and hold **STOP** and press either **PLAY**  or **RECORD**  to step through the Sequence bar by bar.
  - **by event:** Use **CURSOR UP DOWN** to step through the Sequence event by event. Each event will play as it is selected.
  - **“Scrubbing”:** Press and hold **STOP** and turn the **VALUE / TEMPO DIAL** to move fluidly through the events in the Sequence. The Sequence will play back at the speed with which you rotate the **VALUE / TEMPO DIAL**.
- **CURSOR < / > (F3 and F4)** moves the cursor left or right, allowing you to select parameters to edit.
- **DEC- / INC+ or the VALUE / TEMPO DIAL** adjusts the selected parameter.
- **DEL (F1)** will delete the selected event from the Sequence. A window will ask you to confirm this choice before deleting it – select **YES (F4)**, **NO (F3)**, or **TRAK (F1)**, which will delete the entire Sequence.

6. When you have finished making your edits, you can press **EXIT** or any button that will enter another screen (e.g., **KIT SELECT, UTILITIES, etc.**).

Your edits will be retained in the Sequence.



#### How the RBM-20 module's sequencer refers to MIDI note numbers:

When editing the Accompaniment track of a Sequence, you may notice the “Note” column contains the names of musical notes – A4, D#5, etc. However, the name of the note shown here may not be the actual musical note you hear. On the Accompaniment tracks, the bass notes are mapped chromatically to MIDI notes A0 to A3. In other words, when the “Note” column shows a note from A0 to A3, which is the actual note you are hearing the bass play. The Accompaniment tracks also contain other (non-bass, non-drum) samples, such as chords, “hits,” and other sounds. These samples are mapped to MIDI notes C#4 and above – but not in chromatic order, and the collection of samples usually does not contain all chromatic notes.

#### SETTING UP THE CLICK TRACK

The **“click track”** is the click that plays as you record a Sequence.

It is an aid to help you keep steady time. You can edit the click track settings from the Sequence page.

1. Press **SEQ/SONG** to enter the main screen of the Sequencer.

2. Press **CLIK (F3)**. The top of the LCD will show the number of the Sequence but with the title “Click Track” to indicate you are editing the click track settings for the Sequencer. (Note: The click track settings apply to all Sequences.)



3. Use the **CURSOR UP / DOWN** buttons to select settings to edit. Use the **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** to change the settings:

- **Count In:** Indicates when the click track will be heard before the Sequence records or plays. The number of bars can be specified in the **“#Bars”** parameter. When set to **“REC ONLY,”** the count-in clicks will only be heard while recording a Sequence. When set to **“REC + PLAY,”** the count-in clicks track will be heard while recording a Sequence and while playing back a Sequence.


- **#Bars:** The number of bars (2-16) that will be counted by the click track before the module actually begins recording. When set to “OFF,” the Sequence will begin recording as soon as you press the module’s **REC** button with no count-in. When set to “**NOTE ON**,” the Sequence will begin recording from the first note that is sent to it (e.g., when you strike the first trigger, the Sequence will immediately start to record) with no count-in.
  - **Click:** Indicates when the click track will be heard. When set to “**REC ONLY**,” the click track will only be heard while recording a Sequence. When set to “**REC + PLAY**,” the click track will be heard while recording a Sequence and while playing back a Sequence. When set to “**MANUAL**,” the click track will be enabled or disabled by the module’s **CLICK** button.
  - **Sound:** The sound of the click track. When set to “**CLICK**,” the click track will use the **CLICK** settings from the **UTILITIES** Menu (see the **CLIK** (F1) part of the **UTILITIES MENU** section for more information). When set to “**SIMPLE**,” the click track will use the default click sound.
5. When you are finished, you can press **EXIT** or any button that will enter another screen (e.g., **KIT SELECT**, **UTILITIES**, etc.).

### EDITING QUANTIZATION SETTINGS

If the notes of a Sequence are not precisely aligned with a bar’s subdivisions (e.g., eighth notes, 16th notes, etc.), quantization allows you to “snap” them into place automatically.

This page lets you configure the quantization settings for your Sequences:

1. Press **SEQ/SONG** to enter the main screen of the Sequencer.
2. Use the **CURSOR UP / DOWN** buttons to select the “Seq” field at the top of the LCD, then use the **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** to select the Sequence you want to edit.
3. Press **QUAN (F4)**. The top of the LCD will show the number of the Sequence but with the title “Quantize” to indicate you are editing the quantization settings for that Sequence.
4. Use the **CURSOR UP / DOWN** buttons to select settings to edit for that Sequence. Use the **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** to change the settings:



- **Track:** The track of the Sequence – “**DRUMS**” or “**ACCOMP**” (Accompaniment) – to which quantization will be applied.
- **Value:** The subdivision of a bar to which all notes will be quantized. For example, if this set to 1/16, all notes will be “snapped” to the nearest 16th note. The range is 1/4 – 1/64 (regular and triplet) and “**OFF**,” which will turn quantization off.
- **Swing:** The amount of swing applied to the quantization – 54%, 58%, 62%, or “**OFF**.”

5. To apply quantization to the Sequence, press **QUANTIZE (F1 or F2)**. A window will appear to ask you to confirm this choice. Quantization can not be undone, so consider this before confirming. Press **FIX (F4)** to apply quantization or **CANCEL (F2 or F3)** to cancel it.

6. When you are finished, you can press **EXIT** or any button that will enter another screen (e.g., **KIT SELECT**, **UTILITIES**, etc.).

## STORING & COPYING DATA

The RBM-20 module will “remember” changes to your Kit, Sequence, or **UTILITIES** settings during a single session, but you will lose changes you have made once you turn the module’s power off. To save your settings so you can recall them in future sessions, you need to “store” them accordingly.

### NAMING


When storing or copying Kits or Sequences, you can press **NAME (F1)** to enter a new name for the selected Kit or Sequence. In a naming window, the selected character will be highlighted by the cursor. Press **CURSOR < / > (F3 and F4)** to move the cursor. Use the **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** to change the character. When you are done entering a name, press OK (F1).

### STORING & COPYING KITS

1. Press **KIT SELECT** to enter the main screen.
2. Press **SAVE**. A new page will ask you to select **DRUM KIT (F1 or F2)** or **INSTRMENT (F3 or F4)**.
3. Press **KIT SELECT (F1 or F2)**. A new page titled “**SAVE KIT**” will appear.
4. Use the **CURSOR UP / DOWN** buttons to highlight the “From” field of the window.
5. Use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to select the Kit you want to store.
6. Use the **CURSOR UP / DOWN** buttons to highlight the “To” field of the window.
7. Use the **DEC- / INC+ buttons or VALUE / TEMPO DIAL** to select a location to store the Kit. You can store it in any Kit number, though there are 100 empty User Kit slots (#100-199) to choose from.
  - If you want the Kit you are copying to keep the same name in its new location, press **COPY (F2)**.
  - If you want the Kit you are copying to use the name of the Kit currently occupying the “To” slot, press **SAVE (F3 or F4)**.
  - If you want to rename the Kit you are copying, press **NAME (F1)**. Use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to scroll through the available characters, and use the **CURSOR < and > (F3 and F4)** buttons to move the cursor. Press OK (F1) when you are done entering a name, then press **SAVE (F3 or F4)**.



**Note:** By default, the “To” field will initially contain the same Kit number as the “From” field so you can quickly store changes to the current Kit.




8. A window will appear asking you to confirm your choice. Press **CANCEL (F2 or F3)** to cancel storing/copying the Kit. Press **YES (F1)** to store/copy it.



## COPYING INSTRUMENTS



This page allows you to copy an Instrument from one Kit to an Instrument in another Kit. (You can also copy it to the same Kit, which effectively stores that Instrument in that Kit.) Use the **CURSOR UP / DOWN** buttons to select the field you want to edit, and use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to select a new entry in that field.

1. Press **KIT SELECT** to enter the main screen.
  2. Press **SAVE**. A new page will ask you to select **KIT SELECT** (F1 or F2) or **INSTRMENT** (F3 or F4).
  3. Press **INSTRMENT** (F3 or F4). A new page titled "Copy Instrument" will appear.
  4. Make sure the "Copy" field is selected then select the trigger whose Instrument you want to copy.
  5. Select the "From" field.
  6. Select the Kit that contains the Instrument you want to copy.
  7. Select the "To" field.
  8. Select the trigger where you want to copy the Instrument in the "Copy" field.
  9. Select the "To" field then select the Kit where you want to copy the Instrument in the "Copy" field. You can copy it to any Kit, though there are 100 empty User Kit slots (#100-199) to choose from. Copying an Instrument over an existing one will overwrite it.
- Note:** By default, the "Copy" and "To" fields and "From" and "User" fields will initially contain the same settings so you can quickly store changes to the Instruments in your current Kit.
10. Press **SAVE** (F3 or F4).
  11. A window will appear asking you to confirm your choice. Press **CANCEL** (F2 or F3) to cancel storing the Kit. Press **YES** (F1) to store it.



## STORING SEQUENCES

1. Press **SEQ/SONG** to enter the main Sequence page.
  2. Press **SAVE**. A new page titled "Store Sequence" will appear.
  3. Use the **CURSOR UP / DOWN** buttons to highlight the "From" field of the window.
  4. Use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to select the Sequence you want to store.
  5. Use the **CURSOR UP / DOWN** buttons to highlight the "To" field of the window.
  6. Use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to select a location to store the Sequence. You can store it in any Sequence number, though there are 25 empty User Sequence slots (#75-99) to choose from. Storing a Sequence over an existing one will overwrite it.
- Note:** By default, the "To" field will initially contain the same Sequence number as the "From" field so you can quickly store changes to the current Sequence.
7. Press **SAVE** (F3 or F4).
  8. A window will appear asking you to confirm your choice. Press **CANCEL** (F2 or F3) to cancel storing the Sequence. Press **YES** (F1) to store it.



## STORING TRIGGER SETTINGS

Any changes you make to the parameters in the Trig. Edit Menu will remain for the current session but will return to their defaults if you turn off the module. We recommend storing your settings when you change them so you can use them in future sessions.

### To store Trig. Edit settings:

1. Be sure you are in the Trig. Edit Menu by pressing **TRIG EDIT**.
2. Press **SAVE**.
3. A window will appear asking you to confirm your choice. Press **CANCEL (F2 or F3)** to cancel storing your Trig. Edit settings. Press **YES (F1)** to store them.



## TRIG EDIT MENU

The RBM-20's Trig. Edit Menu contains several pages of parameters related to triggering (striking pads, cymbals, etc.). The settings in these pages affect ALL Kits.

## TRIGGER INPUT PARAMETERS

The **INP** page of the Trig. Edit Menu contains some parameters that affect the triggers' sensitivity and function within the module.

1. Press **TRIG EDIT** to enter the main **Trig. Edit Menu** page.

The first page shown should be **INP (F1)**.

2. Select the trigger whose parameters you want to edit by pressing **PAD ID** then striking the desired trigger. Alternatively, you can highlight the trigger name at the top of the screen using the **CURSOR UP / DOWN** buttons to highlight it and use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to change it.

3. Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** to adjust the settings:


- **Sensitivity:** The gain control for the trigger (00-99). The higher the setting, the easier it will be to trigger louder sounds with lighter hits. When setting this parameter, strike the trigger and watch the level meter in the upper right hand corner of the LCD. If it is "clipping" or maxing out too soon, reduce this setting. The meter should only reach its maximum when you are striking the trigger at your hardest.
- **Function:** You can assign different functions for the trigger to execute when you strike it:
- **Trigger:** The associated drum Voice will sound when you strike the trigger.
- **Next Kit:** The current Kit number will increase by one when you strike the trigger.
- **Prev Kit:** The current Kit number will decrease by one when you strike the trigger.
- **Tap Tempo:** The trigger will function as the TAP TEMPO button, entering a new tempo for the sequencer when struck repeatedly.
- **Seq Play:** Striking the trigger will play the current Sequence.
- **Seq Stop:** Striking the trigger will stop the currently playing Sequence.
- **Play/Stop:** The trigger will function alternately as a "play/stop" button for the current Sequence. Striking the trigger once will start playback; striking it during playback will stop the Sequence.

- **Record:** The trigger will function as a "record" button for the sequencer.

- **Rec/Stop:** The trigger will function alternately as a "record/stop" button for the sequencer.

Striking the trigger once will start recording; striking it during recording will stop it.

- **InputType:** Select the type of trigger you have connected to the input. Select "**PIEZO**" for triggers like pads or cymbals. Select "**SWITCH**" if you are using a drum pad with a rim switch, a cymbal with an edge switch, or a footswitch. (Note: This parameter is only seen on certain pages.)



**Note:** The **UTILITIES** Menu allows you to set the rough "global" sensitivity of all triggers in the Kit ("Trig Sens"). See the **UTILITIES MENU** chapter for more information.

**Note:** When assigning a function other than "Trigger," be sure that the physical (hardware) trigger is placed in such a way that it will not receive "crosstalk" or otherwise accidentally trigger as you perform.

4. When you have finished making your edits, you can press **EXIT** or any button that will enter another screen -e.g., **KIT SELECT, UTILITIES**, etc. Your edits will remain for that session (i.e., until you turn off the module).

## TRIGGERING PARAMETERS

The **TRIG** page of the Trig. Edit Menu contains some parameters that affect the triggers' sensitivity and function within the module.

1. Press **TRIG EDIT** to enter the main Trig. **Edit Menu** page. Press **TRIG (F2)**.

2. Select the trigger whose parameters you want to edit by pressing **PAD ID** then striking the desired trigger.

Alternatively, you can highlight the trigger name at the top of the screen using the **CURSOR UP / DOWN** buttons to highlight it and use the **DEC- / INC+** buttons or **VALUE DIAL** to change it.

3. Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** to adjust the settings:

- **Xtalk Rcv \***: How susceptible the trigger is to “crosstalk” from other triggers (00-07). The higher the value, the less likely crosstalk from other triggers will affect it.
  - **Xtalk Snd \***: How likely the trigger will cause “crosstalk” in other triggers (00-07). The higher the value, the less likely it will be a source of crosstalk on other triggers.
  - **Retrigger**: How quickly the module processes repeated strikes of the same trigger (00-99). This is the minimum amount of time needed between successive strikes of the same trigger for the second one to produce a sound. (For instance, if your Retrigger setting is 50 and you strike the trigger once, it will produce a sound if the next strike is at least 50 milliseconds later. Otherwise, it will be silent.) (Note: This parameter is only seen on certain pages since it already affects both zones of a drum pad or cymbal that “share” the same **TRIGGER INPUT**.)
  - **Threshold**: How much velocity (force) is required for a Voice to sound (00-99). At lower settings, very light strikes of the triggers will produce sounds. At higher settings, you will need to strike the triggers harder to produce a sound. (Note: This parameter is only seen on certain pages since it already affects both zones of a drum pad or cymbal that “share” the same **TRIGGER INPUT**.)
  - **ZoneXtalk**: This setting adjusts how susceptible triggers on a “shared” input (e.g., the bell and bow of a ride cymbal, or the head and rim of a the same drum pad) are to “crosstalk” from each other. The higher the setting, the less likely these trigger pairs will cause each other to trigger unintentionally. (Note: We recommend increasing this setting for drum pads on which you want to produce “rimshots” by striking the head and rim simultaneously.)
4. When you have finished making your edits, you can press **EXIT** or any button that will enter another screen (e.g., **KIT SELECT, UTILITIES**, etc. Your edits will remain for that session (i.e., until you turn off the module).

```
Input: SnrHd
Xtalk Rcv : 03
Xtalk Snd : 04
ReTrigger : 15
Threshold : 15
INP TRIG CURV
```

```
Input: SnrRim
Xtalk Rcv : 01
Xtalk Snd : 07
ZoneXtalk : 00
INP TRIG CURV
```

### \* A note about crosstalk:

“Crosstalk” occurs when a trigger is struck and the vibration from that strike is also “read” as a strike by an adjacent trigger. For instance, if you strike the snare drum hard enough, it is possible for the crash cymbal to sense the vibration of your hit (especially if they are mounted on the same rack) and trigger as well. This unintentional triggering can be reduced or eliminated by adjusting the RBM-20 module’s crosstalk (“**Xtalk**”) settings.

- When you increase a trigger’s “**Xtalk Rcv**” (“**Crosstalk Receive**”) setting, you are making that trigger less susceptible to crosstalk from other triggers’ vibrations.
- When you increase a trigger’s “**Xtalk Snd**” (“**Crosstalk Send**”) setting, you are making that trigger less likely to be interpreted by the module as a cause of crosstalk.

In a general sense, these two settings essentially do the same thing: reduce crosstalk. However, there are cases where adjusting one is better than adjusting the other:

#### **Example:**

While playing, if you find the first tom is unintentionally triggering as you play heavily on the snare drum, you should increase the first tom’s “**Xtalk Rcv**” setting to reduce its sensitivity to strikes on the snare drum (as well as other triggers). On the other hand, if you find playing heavily on the snare drum is unintentionally causing several triggers to sound, you should increase the snare drum’s “**Xtalk Snd**” setting so the module interprets vibrations from the snare drum more strictly to reduce errant triggering on the rest of the kit.

## VELOCITY CURVE

The **CURV** page lets you set the velocity curve for the triggers, which determines how a sound's volume is affected by how hard you strike it – that is, how responsive the triggers' dynamics are to changes in your playing.





1. Press **TRIG EDIT** to enter the main **Trig. Edit** Menu page. Press **TRIG (F2)**.

2. Select the trigger whose parameters you want to edit by pressing **PAD ID** then striking the desired trigger. Alternatively, you can highlight the trigger name at the top of the screen using the **CURSOR UP / DOWN** buttons to highlight it and use the **DEC-/INC+** buttons or **VALUE / TEMPO DIAL** to change it.

3. Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** to adjust the settings:

- **Linear:** The triggers will be consistently responsive to changes in your playing, increasing at the same rate as the force of your hits.
- **Log 1-4:** The triggers will be more responsive to changes in your playing at lower velocities and become less responsive at higher velocities.
- **Exp 1-4:** The triggers will be more responsive to changes in your playing at higher velocities and become less responsive at lower velocities.
- **Spline 1-4:** The triggers will be more responsive to changes in your playing at lower and higher velocities and less responsive at moderate velocities.
- **Offset:** The triggers will be consistently responsive to changes in your playing at lower and medium velocities and play sounds at the maximum volume at high velocities.
- **Constant:** The triggers will play sounds at the maximum volume regardless of how hard or soft you hit them.

4. When you have finished making your edits, you can press **EXIT** or any button that will enter another screen (e.g., **KIT SELECT, UTILITIES**, etc). Your edits will remain for that session (i.e., until you turn off the module).



## MODE (RIDE BOW & BELL)

You should adjust this setting for the kind of ride cymbal you are using – a dual-zone ride (which has bow and bell triggers) or a three-zone ride (which has edge, bow, and bell triggers).

To do this:


1. Press **TRIG EDIT** to enter the main **Trig. Edit** Menu page.

2. Select the ride's bow or bell by pressing **PAD ID** then striking that zone on your cymbal trigger. Alternatively, you can highlight the trigger name at the top of the screen using the **CURSOR UP / DOWN** buttons to highlight it and use the **DEC-/INC+** buttons or **VALUE / TEMPO DIAL** to select either "RideBell" or "RideBow."

3. Press **MODE (F4)**.

4. Use **DEC- / INC+** buttons or the **VALUE / TEMPO DIAL** to select "2 Zones" if your ride cymbal is a dualzone or "3 Zones" if your ride cymbal is a three-zone.


5. When you have finished making your edits, you can press **EXIT** or any button that will enter another screen (e.g., **KIT SELECT, UTILITIES**, etc). Your edits will remain for that session (i.e., until you turn off the module).



## HI-HAT CALIBRATION




The Hi-hat calibration is pre-set at the factory with the TRIM settings set at **OPEN = 75** and **CLOSED = 12** for great playability out-of-the-box.

**However, if you want to customize your hi-hat settings or are using a different Hi-hat controller, you can calibrate the Hi-hat as follows.**



### To calibrate the Hi-hat pedal:

1. Connect the Hi-hat pedal to the module but do not press it down.
2. On the module, press **TRIG EDIT**.
3. Use the **CURSOR UP / DOWN** buttons to highlight the "Input" field at the top of the screen then use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to select "HiHat."
4. Press **CAL (F4)**.
5. With the hi-hat pedal completely raised ("open"), press **OPEN (F1)** and wait for a message saying the process is complete.
6. With the hi-hat pedal completely pressed ("closed"), press **CLOS (F2)** and wait for a message saying the process is complete.
7. If you want to fine-tune how the module detects your pedal's "open" and "closed" positions, press **TRIM (F3)**. Use the **CURSOR UP / DOWN** buttons to select "Open" or "Closed" and use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to adjust the setting. (Tip: Increasing the "Closed" value makes it easier to close the hi-hat or "choke" it.)  
You can always reset the TRIM to the factory settings by setting **OPEN = 75** and **CLOSED = 12**.
8. If you want to adjust the response curve of the pedal, press **CURV (F2)**. Use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to select the curve that best suits your playing style. (Tip: We recommend using **LINEAR**, **LOG1** or **LOG2** for conventional hi-hat performance.)
9. When you have adjusted the hi-hat settings to your preference, press **EXIT** to exit the calibration page (or press **KIT SELECT** to return to the main screen).



## STORING TRIG EDIT SETTINGS

Any changes you make to the parameters in the **Trig. Edit Menu** will remain for the current session but will return to their defaults if you turn off the module.

We recommend storing your settings when you change them so you can use them in future sessions.

### To store Trig. Edit settings:

1. Be sure you are in the **Trig. Edit Menu** by pressing **TRIG EDIT**.
2. Press **SAVE**.
3. A window will appear asking you to confirm your choice. Press **CANCEL (F2 or F3)** to cancel storing your Trig. Edit settings. Press **YES (F1)** to store them.



## EXPLORING OPTIMAL SENSITIVITY AND THRESHOLD SETTINGS

We created the RBM-20 module's default settings to allow for great playability right out of the box, but we recommend experimenting with different triggers settings – particularly sensitivity and threshold – so you can find the settings that best suit your playing style. Here is one recommended way to explore these settings:

1. Press **TRIG EDIT** to access the trigger settings.
2. Make sure **PAD ID** is activated (the LED should be lit).
3. Strike a trigger on your electronic drum kit whose settings you want to adjust. The name of the trigger will be displayed at the top of the module's LCD.
4. On the **INP** page, adjust the "Sensitivity" setting to an appropriate level as you strike the trigger with moderate force, typical of how you play. The resulting sound should be neither too loud nor too quiet. (Make sure the "**Function**" setting is set to "**TRIGGER.**") If the level meter in the upper-right hand corner is "clipping" or maxing out too soon, reduce the sensitivity.
5. On the **TRIG** page, adjust the "Threshold" setting to an appropriate level as you strike the trigger as lightly as you would while playing. You can use the level meter in the upper right-hand corner of the module's LCD to see whether the module is detecting your hits.
6. After setting the threshold, return to the **INP** page and readjust the "**Sensitivity**" setting as you strike the trigger with varying force.
7. Repeat this process for other triggers in your electronic drum kit.
8. Press **SAVE** to save these changes.

Note that you can also adjust the velocity curve for each trigger, which can help in the "shaping" of the triggers' volume levels relative to the range of force you use while playing. Also, the **UTILITIES** Menu allows you to set the rough "global" sensitivity of all triggers in the Kit. ("**TRIG**") See the **UTILITIES MENU** chapter for more information.

## UTILITIES MENU

The RBM-20's UTILITIES Menu contains several pages of parameters that affect the module's overall operation as well as system-related information and functions.

### GENERAL

The main page of the **UTILITIES** Menu contains some global parameters that affect the kit as well as the module itself.

1. Press **UTILITIES** to enter the main **UTILITIES** Menu page.
2. Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+ or the VALUE / TEMPO DIAL** to adjust the settings:

- **Tempo:** Indicates how the module determines tempo from pattern to pattern. When set to "**PATTERN**," each Pattern will have its own tempo (i.e., the tempo can change when moving from one Pattern to the next). When set to "**GLOBAL**," the module will follow a fixed, global tempo, ignoring the tempo specific to a pattern.
- **Output:** Determines the module's output routing. When set to "**MAIN&AUX**," the Drums and Accompaniment tracks will be sent through the **MAIN OUT** with effects applied and through the **AUX OUT** without effects applied ("dry"). When set to "**MAIN>AUX**," the signal sent through the **AUX OUT** will be identical to the one sent through the **MAIN OUT**.
- **Acc Pitch:** The tuning of the module's Accompaniment. The default is a standard "A=440Hz." The available tuning range is 430 – 450 Hz.
- **Contrast:** The contrast of the LCD (0-99).

```
Utilities:General
  Tempo : PATTERN
  Output : MAIN&AUX
  Acc Pitch : A=440Hz
  Contrast : 60
  CLK MIDI TRIG SYS
```

### CLICK (F1)

Pressing **CLICK (F1)** from the main **UTILITIES** Menu lets you access pages that contain the settings for the module's click.

```
Utilities:Click
MeasLvl : 85
MeasSnd : Stick Click
BeatLvl : 45
BeatSnd : A9090
MEAS SUBD TAP OUT
```

## MEASURE (F1)

1. Press **UTILITIES** to enter the main **UTILITIES** Menu.

2. Press **CLIK (F1)** to access the click settings. The first page to appear will be **MEAS (F1)**.

3. Use **CURSOR UP / DOWN** to move through the menu

items and **DEC- / INC+ or the VALUE / TEMPO DIAL** to adjust the settings:

- **MeasLvl:** The volume level of the first click beat of every measure (00-99).  
(The first beat is often louder than the others to mark the beginning of each bar.)
- **MeasSound:** The sound of the first click beat of every measure.  
(The first beat is often at a slightly higher pitch than the others to mark the beginning of each bar.)
- **BeatLevel:** The volume level of the overall click beat (00-99).
- **BeatSound:** The sound of the click beat.

```
Utilities:Click
MeasLvl : 85
MeasSnd : Stick Click
BeatLvl : 45
BeatSnd : A9o9o
MEAS SUBD TAP OUT
```

## SUBDIVISION (F2)

This page lets you adjust settings for the subdivision click.

This is similar to the regular click but while the regular click sounds every beat, the subdivision click sounds during smaller intervals of each measure.

1. Press **UTILITIES** to enter the main **UTILITIES** Menu.

2. Press **CLIK (F1)** to access the click settings.

3. Press **SUBD (F2)** to access the subdivision click settings.

4. Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+ or the VALUE DIAL** to adjust the settings:

- **SubDvsn:** The length of each subdivision. The range includes OFF, 1/4, 1/8, 1/16, 1/32 and 1/64 notes – both regular and triplet. (Example: If the regular click is set to a 4/4 time signature and “**SubDvsn**” is set to “1/8,” you will hear the regular click on every 1/4 note as well as the subdivision click on every 1/8 note.)
- **SubDLvl:** The volume level of the subdivision click sound (00-99). We recommend keeping this volume relatively low so it is not confused with the regular click sound.
- **SubDSnd:** The sound of the subdivision click.

```
Utilities:Click
SubDvsn : 1/4
SubDLvl : 15
SubDSnd : Doumbek 1
MEAS SUBD TAP OUT
```

## TAP TEMPO (F3)

This page lets you adjust settings for the **TAP TEMPO** button and the tempo LED.

1. Press **UTILITIES** to enter the main **UTILITIES** Menu.

2. Press **CLIK (F1)** to access the click settings.

3. Press **TAP (F3)** to access the Tap Tempo settings.

4. Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+ or the VALUE / TEMPO DIAL** to adjust the settings:

- **Tempo LED:** This setting lets you control when the tempo LED will be seen. When set to “ON,” the tempo LED will flash all the time. When set to “**PAT ONLY**,” the tempo LED will only flash when a Sequence is playing. When set to “**OFF**,” the tempo LED will never be seen.
- **Tap Tempo:** Enables or disables the **TAP TEMPO** button. Disabling it may be useful if you do not want to make any unintentional changes to a Sequence’s tempo.

```
Utilities:Click
Tempo LED : PAT ONLY
Tap Tempo : ON
MEAS SUBD TAP OUT
```

## CLICK ROUTING (F4)

This page lets you select the module’s outputs through which the click sounds will be sent. This can be useful for maintaining two separate mixes. (For instance, you may want to have a monitor mix with the click sent to you through the **AUX OUT**, but you want to have a separate mix without the click for the house PA system.)

1. Press **UTILITIES** to enter the main **UTILITIES** Menu.

2. Press **CLIK (F1)** to access the click settings.

```
Utilities:Click
OutAssign : MAIN
MEAS SUBD TAP OUT
```

3. Press **OUT (F4)** to access the click output settings.

4. Use **DEC- / INC+** or the **VALUE / TEMPO DIAL** to adjust the settings:

- **OutAssign:** This setting lets you assign the output through which the click sound will be sent. When set to **"MAIN,"** the click will be sent out both channels of the **MAIN OUT**. When set to **"AUX,"** the click will be sent out both channels of the **AUX OUT**. You can also select **"AUX L"** or **"AUX R,"** which lets you send it out only one of the **AUX OUT** channels.

Note: If the "Output" setting on the main **UTILITIES** Menu is set to **"MAIN>AUX,"** this means the signal sent out the **MAIN OUT** will also be sent out the **AUX OUT**. In this case, the "OutAssign" settings for the **AUX OUT** will display **"(N/A)"** next to it, indicating the click will not be heard over this channel. (To make the **AUX OUT** available for the click sound, change the "Output" setting on the main **UTILITIES** Menu to **"MAIN&AUX."**)

## MIDI (F2)

Pressing **MIDI (F2)** from the Main **UTILITIES** menu lets you access pages that contain the module's MIDI settings.

### INPT (F1)

This page controls the module's MIDI input settings.

1. Press **UTILITIES** to enter the main **UTILITIES** Menu.
2. Press **MIDI (F2)** to access the MIDI settings. The first page to appear will be **INPT (F1)**.
3. Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+** or the **VALUE / TEMPO DIAL** to adjust the settings:

- **Drum Chan:** The MIDI channel number over which the drum sounds will be received (**01-16** or **"OMNI,"** which sends it over all 16 channels) when played by an external MIDI device.
- **Acc Chan:** The MIDI channel number over which the Accompaniment will be received (01-16 or "OMNI," which sends it over all 16 channels) when played by an external MIDI device.
- **LocalCont:** This "Local Control" setting determines whether the module receives MIDI messages from the triggers or an external source. When set to **"ON"** (the default), the module's sounds will receive MIDI messages from your connected triggers. Switch this setting to **"OFF"** when you are using an external **MIDI** sequencer. (When using an external sequencer, if this setting is **"ON,"** each note will be triggered twice – once in the module and once via the external sequencer. **Turning Local Control "OFF"** ensures you will hear the triggered note only once.)

```
Utilities:MIDI Inpt
Drum Chan : 10
Acc Chan : 01
LocalCont : ON
INPT EXT OUT
```

### EXT (F2)

This page's settings determine how the module responds to external MIDI controllers.

1. Press **UTILITIES** to enter the main **UTILITIES** Menu.
2. Press **MIDI (F2)** to access the MIDI settings.
3. Press **EXT (F2)** to access the external MIDI settings.
4. Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+ or the VALUE / TEMPO DIAL** to adjust the settings:

- **Prog Chng:** Determines if the module will recognize Program Change messages from external MIDI sources. When set to **"OFF"** (the default), the module will ignore Program Change messages. When set to **"RECEIVE,"** Kits can be selected via Program Change messages from external sources.
- **Clock In:** Determines if the module will sync to an external MIDI clock. When set to **"OFF"** (the default), the module will run off its internal clock. When set to **"RECEIVE,"** the module's clock will sync to the "master" clock of a connected external MIDI source.

```
Utilities:External
Prog Chng : OFF
Clock In : OFF
INPT EXT OUT
```

### OUT (F3)

This page controls the module's MIDI output settings.

1. Press **UTILITIES** to enter the main **UTILITIES** Menu.
2. Press **MIDI (F2)** to access the MIDI settings.
3. Press **OUT (F3)** to access the MIDI output settings.
4. Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+ or the VALUE / TEMPO DIAL** to adjust the settings:

```
Utilities:Output
Prog Chng : NOT SENT
Clock Out : NOT SENT
MIDI Thru : ENABLED
INPT EXT OUT
```



- **Prog Chng:** Determines if the module will send out Program Change messages to external MIDI devices. When set to “**NOT SENT**” (the default), the module will not send any Program Change messages. When set to “**SENT**,” the module will send Program Change messages to a connected MIDI device.
- **Clock Out:** Determines if the module’s internal clock will serve as the “master” clock for a connected MIDI device. When set to “**NOT SENT**” (the default), the module will not send out any MIDI clock information to a connected device. When set to “**SENT**,” a connected MIDI device will sync to the module’s internal clock.
- **MIDI Thru:** When set to “**ENABLED**” (the default), the module’s **MIDI OUT** functions as a **MIDI THRU**. In this case, a device connected to the module’s **MIDI IN** can send data through the module to a device connected to the module’s **MIDI OUT**. When set to “**OFF**,” the module’s **MIDI OUT** functions only as a MIDI output for the module itself.

### TRIG (F3)

Pressing **TRIG (F3)** from the Main **UTILITIES** menu lets you access a page that contains the various trigger settings for the module.

#### TRIG

1. Press **UTILITIES** to enter the main **UTILITIES** Menu.
2. Press **TRIG (F3)** to access the trigger settings.
3. Use **DEC- / INC+** or the **VALUE / TEMPO DIAL** to adjust the settings:



- a. Trig Sens:** The sensitivity of all the connected triggers – “**LOW**,” “**MEDIUM**,” or “**HIGH**.” Adjusting this setting lets you roughly set the sensitivity of the entire Kit but conveniently keeps the proportions of your individual trigger settings. (To adjust the sensitivity of individual triggers, see the **TRIGGER INPUT PARAMETERS** section of the **TRIG. EDIT MENU** chapter.)
- b. HiHat \* :** Select “**NOTE+CC#4**” or “**NOTE ONLY**.” This determines whether the hi-hat MIDI note will be sent with or without CC information (CC#4).
- c. HH Splash \* :** Select “**SENT**” or “**NOT SENT**.” This determines whether the hi-hat “splash” note (generated by quickly pressing then releasing the pedal) will be sent or not.
- d. Cym Choke \* :** Select “**SENT**” or “**NOT SENT**.” This determines whether the cymbal “choke” note (generated by grabbing the cymbal and touching the choke strip) will be sent or not.

\* Note: The “HiHat,” “HH Splash,” and “Cym Choke” parameters allow you to tailor the MIDI output of these notes, which is useful when using the module with an external hardware or software drum module that does not support a variable hi-hat pedal, the hi-hat “splash,” cymbal choking, etc. Also, even when these parameters are set to “NOTE ONLY” or “NOT SENT,” the MIDI notes and information you have “disabled” will actually still be recorded when you record a Sequence, but they will not be sent to the MIDI output.

### SYS (F4)

Pressing **SYS (F4)** from the Main **UTILITIES** menu lets you access a page that contains the module’s various system settings.


#### SYSX (F1)

This page lets you send out the module’s settings as a **SysEx (.sxx)** file to be recalled later.

1. Press **UTILITIES** to enter the main **UTILITIES** Menu.1).
2. Use **CURSOR UP / DOWN** to move through the menu items:
  - a. All Memory:** All of the module’s memory that can be saved will be saved as a SysEx file.

This includes your trigger settings, Kits, and Sequences.

- b. All Trigger Settings:** Only the module’s trigger settings will be saved as a SysEx file. will be saved as a SysEx file.



1. Press **UTILITIES** to enter the main **UTILITIES** Menu.1).
2. Use **CURSOR UP / DOWN** to move through the menu items:
  - a. **All Memory:** All of the module's memory that can be saved will be saved as a SysEx file. This includes your trigger settings, Kits, and Sequences.
  - b. **All Trigger Settings:** Only the module's trigger settings
3. Press **SEND (F4)** to send the selected settings from the module as a SysEx file.

### INIT (F2)

This page lets you reinitialize different settings in the module, restoring them to their factory defaults.

1. Press **UTILITIES** to enter the main **UTILITIES** Menu.
2. Press **SYS (F4)** to access the Accompaniment settings.
3. Press **INIT (F2)** to access the reinitialization page.
4. Use **CURSOR UP / DOWN** to move through the menu items:
  - a. **All Kits:** All of the module's Kits and their settings will return to their factory defaults.
  - b. **All Sequences:** All of the module's Sequences and their settings will return to their factory defaults.
  - c. **All Trigger Settings:** All of the module's trigger settings will return to their factory defaults.
5. Press **EXEC (F4)**.
6. A window will appear asking you to confirm your choice. To confirm and reinitialize the selected settings, press **YES (F1)**. To cancel, press **CANCEL (F2 or F3)**.

```
Utilities:ReInit
Select option, EXEC
All Kits
All Sequences
All Trigger settings
SYSX INIT O/S EXEC
```

```
Are you sure?
Initialize all
drum kits?
YES CANCEL
```

### O/S (F3)

This page contains information about the module's current operating systems and sound **ROM**.

1. Press **UTILITIES** to enter the main **UTILITIES** Menu.
2. Press **SYS (F4)** to access the Accompaniment settings.
3. Press **O/S (F3)** to access the operating system information page.
4. This page contains the version numbers of the module's current software:
  - a. **Trig OS:** The current version number of the trigger firmware.
  - b. **Sound ROM:** The current version number of the sound ROM – the library of sounds read by the module.
  - c. **Sound OS:** The current version number of the module's own firmware.

```
Utilities:O/S
Trig OS : 01.00
Sound ROM : 01.00
Sound OS : 01.00
SYSX INIT O/S MEM
```

**Note:**  
Be sure to register your RBM-20 module at [www.pearlsoundshop.com](http://www.pearlsoundshop.com) to be notified if new software becomes available.

### MEM (F4)

This page contains information about the module's available memory and lets you enable or disable write protection.

**Note:** There are no editable parameters on this page.

1. Press **UTILITIES** to enter the main **UTILITIES** Menu.
2. Press **SYS (F4)** to access the Accompaniment settings.
3. Press **INIT (F2)** or **O/S (F3)** to change the available **FBUTTON** tabs. **MEM (F4)** will become available.
4. Press **MEM (F4)** to access the memory page.
5. This page contains two items:
  - a. **Memory:** The amount of currently available module memory.
  - b. **WriteProt:** Use the **DEC- / INC+** buttons or **VALUE / TEMPO DIAL** to enable or disable write protection. When set to "**ON**" (the default), you can make changes to the Kits, Instruments, Sequences, etc., but will not be able to store them. When set to "**OFF**," you can store these settings.

```
Utilities:Memory
Memory : 99% FREE
WriteProt : OFF
SYSX INIT O/S MEM
```

## UPDATING THE MODULE

To update the module, follow these steps:

1. If you have not done so already, download the **Redbox Updater** Application from [www.redboxsoundshop.com](http://www.redboxsoundshop.com) (under the Customer Support tab.)
2. Connect the module's USB port to your computer with a standard USB cable.
3. Press and hold the module's **REC** button while turning it on. (Windows users: If you see a message that says Windows was unable to install a driver, ignore it.)
4. Open the RBM-20 Redbox Updater Application.
5. Windows users: Select "**USB Audio Device**" (the RBM-20 module) from the "MIDI Interface" dropdown menu.  
Mac users: The RBM-20 module will be automatically selected.
6. Drag the appropriate file onto the application, or click "**File**" then "**Open**" and select the file.  
You can upload SysEx (.syx) files – such as sound ROM files or firmware files – in this fashion.

### Note:

**Third party sound ROMs are also considered updates and can be loaded to the RBM-20 module in this fashion.**

### Note:

**If you encounter an error message while switching on the module, it is possible the sound ROM cannot be read correctly. In this case, reload the sound ROM file and try again.**

**Note:** Since the release of this module, we may have released new firmware or sound ROM files. To keep your module current, we recommend checking the Customer Support tab of [www.redboxsoundshop.com](http://www.redboxsoundshop.com) for available updates for your RBM-20 module.


## MIDI SETUP

You can use the RBM-20 module as a trigger-to-MIDI interface, allowing you to use your electronic drum kit to trigger sounds from external sound libraries. This means you can use your hardware kit to play sounds in software drum modules like BFD, Toontrack, Reason, and many others.

You can also use external MIDI devices – such as MPCs, or other MIDI controllers – to trigger sounds from the RBM-20's own extensive sound library instead of (or in addition to) the electronic drum kit.

To use the RBM-20 in these ways, you will need to set it up to communicate with your external device(s) via MIDI. Here are a couple examples of how to do this.

## Using the RBM-20 to trigger sounds from a software drum module:



1. Connect the module's USB port to your computer with a standard USB cable. (Alternatively, you could connect the **MIDI OUT** of the RBM-20 to the MIDI IN of a MIDI interface connected to your computer, but we recommend using your computer's USB connection if it is available.)
2. Press **UTILITIES** to access the module's UTILITIES Menu.
3. Press **MIDI (F2)** to access the MIDI settings.
4. Press **OUT (F3)** to access the MIDI output settings.
5. Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+** or the **VALUE / TEMPO DIAL** to adjust the settings accordingly:
  - a. **Prog Chng:** "SENT" (so the RBM-20 can send Program Change messages to the software).

**b. Clock Out:** "SENT" (if you want the RBM-20's MIDI clock to be the "master" clock) or "NOT SENT" (if you do not want the RBM-20 to send out MIDI clock information).


**c. MIDI Thru:** "OFF."

6. Set your software to receive MIDI messages from the RBM-20 module ("**USB Audio Device**"). Consult your software's manual for more information.

### Note:

These are just recommended settings. You may configure the RBM-20's MIDI settings however best suits your performance needs. See the MIDI section of the UTILITIES MENU chapter and the KIT SELECT SETUP section of the KITS, VOICES, ACCOMPANIMENT & INSTRUMENTS chapter for more information.

Using an external MIDI device with the RBM-20's sound library:



1. Connect the RBM-20's **MIDI IN** port to your external device's MIDI OUT port using a standard MIDI cable.
2. Press **UTILITIES** to access the module's **UTILITIES** Menu.
3. Press **MIDI (F2)** to access the MIDI settings.
4. Press **INPT (F1)** to access the MIDI input settings.
5. Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+** or the **VALUE / TEMPO DIAL** to adjust the settings accordingly:
  - a. **Drum Chan:** Set this to the MIDI channel (**01-16** or "**OMNI**") over which the drum sounds will be received when played by your external device.
  - b. **Acc Chan:** Set this to the MIDI channel (01-16 or "**OMNI**") over which the Accompaniment sounds will be received when played by your external device.
  - c. **LocalCont:** "**OFF**" (otherwise, each note you trigger will be heard twice)
6. Press **EXT (F2)** to set how the RBM-20 will respond to the external device.
7. Use **CURSOR UP / DOWN** to move through the menu items and **DEC- / INC+** or the **VALUE / TEMPO DIAL** to adjust the settings accordingly:
  - a. **Prog Chng:** "**RECEIVE**" (so the RBM-20's Kits can be selected via Program Change messages from the external device).
  - b. **Clock In:** "**OFF**" (if you want the RBM-20 to run off its own internal clock) or "**RECEIVE**" (if you want to sync the RBM-20's clock to the clock of your external device).
8. Set your external device's settings to send MIDI to the RBM-20 module. Consult your software's manual for more information.

**Note:**

These are just recommended settings. You may configure the RBM-20's MIDI settings however best suits your performance needs. See the MIDI section of the UTILITY MENU chapter and the KIT SELECT SETUP section of the KITS, VOICES, ACCOMPANIMENT & INSTRUMENTS chapter for more information.

## Midi Implementation Chart

	Transmit/Export	Recognize/Import	Remarks
<b>1. Basic Information</b>			
MIDI channels	1-16	1-16	Drums: 10 (default) Accomp: 1 (default)
Note numbers	0-127	Drums: 28-91 Accomp: 0-127	
Program change	0-99	0-99*	*Used for selecting active kit
Bank Select response?	Yes	Yes*	*0: Kits 0-99, 1: Kits 100-199
Modes supported: Mode 1: Omni-On, Poly Mode 2: Omni-On, Mono Mode 3: Omni-Off, Poly Mode 4: Omni-Off, Mono Multi Mode	Yes Yes Yes Yes Yes	Yes Yes Yes Yes Yes	
Note-On Velocity	Yes	Yes	
Note-Off Velocity	No	No	
Channel Aftertouch	No	No	
Poly (Key) Aftertouch	No	No	
Pitch Bend	Yes	Yes	For Basses Only
Active Sensing	No	No	
System Reset	No	No	
Tune Request	No	No	
Universal System Exclusive	No	No	
Manufacturer or Non-Commercial System Exclusive	Yes	Yes	Used for backup / restore and loading new sound sets
NRPNS	No	Yes	See MIDI Implementation Supplement
RPNS	No	No	
<b>2. MIDI Timing and Synchronization</b>			
MIDI Clock	Yes	Yes	
Song Position Pointer	Yes	No	
Song Select	No	No	
Start	Yes	Yes	
Continue	Yes	Yes	
Stop	Yes	Yes	
MIDI Time Code	No	No	
MIDI Machine Control	No	No	
MIDI Show Control	No	No	
<b>3. Extensions Compatibility</b>			
General MIDI compatible?	No	Partial	GM Drum Sounds compatible
DLS compatible?	No	No	
Standard MIDI Files	No	No	
XMF Files	No	No	
SP-MIDI compatible?	No	No	

## RBM-20 Sequences

### JAZZ

Bob's Bop  
Chili  
Did He Do Dat?

### FUNK

Yaba Daba Baba  
On the 1  
Greens, Grits & Onions  
Dat's What I'm Talkn Bout  
Not Here!

### METAL

Trust in No One  
Bottom Feeders  
Serpents Servant  
Loud, Fast, and Hard  
Locked & Loaded

### FUSION

Islands  
ANother One Please  
Feel This  
4Ever

### HIP-HOP

Shorty's Here  
Slammin Jammin  
Hop Hood

### ROCK

Bangers Head  
Up 4 It  
OZ E  
#13

### LATIN

A Bene Placito  
Acta Non Verba  
In Cuba

## RBM-20 Kits

0	AC	1Up 2Down	34	AC	GreenEyed	68	AC	ThundaCrak
1	AC	Heartland	35	AC	SnareYaGo	69	AC	Doubt N It
2	AC	StudioCity	36	AC	VintageMod	70	AC	ShuffEnuff
3	AC	NowMetal	37	WL	EastrnTrip	71	AC	Pop Roxx
4	AC	ShoTime	38	AC	Music Row	72	WL	CariBeing
5	AC	ModJazz	39	EL	TurnTable	73	AC	Funk Wave
6	AC	Picante	40	EL	TranzDance	74	AC	Fuse On
7	AC	80sMonster	41	AC	BoardTape	75	AC	Fat 70's
8	EL	Wonder Gig	42	EL	9Inch	76	WL	Nat Geo
9	AC	NashVegas	43	AC	Arena Live	77	AC	Funk Broz
10	EL	HoodHop	44	AC	Classic Mo	78	AC	Word Up
11	AC	70'sVibe	45	AC	Bourbon St	79	AC	Magic Man
12	AC	Dub It Up!	46	CL	SoundTrack	80	AC	Purple Jam
13	AC	HydroGate	47	AC	Brushes	81	WL	Taj Funk
14	AC	RockABye	48	AC	70's Alive	82	EL	Hoppy Daze
15	AC	Headbanger	49	EL	TechnoEcho	83	AC	RockSteady
16	AC	TempTasty	50	WL	Bollywood	84	AC	Hyperspeed
17	AC	CocktailIt	51	AC	Poppin	85	AC	2-3 Floor
18	AC	Big Ballad	52	AC	Chunky Jam	86	AC	DeepGroove
19	EL	SpaceCake	53	WL	Kenya Hear	87	AC	SalsaTimbl
20	EL	8HUNDRED8	54	CL	StarStripes	88	AC	DryClean
21	HY	Mi Casa	55	HY	St. Beatz	89	AC	Uptight
22	AC	Punchy	56	AC	Low&Tight	90	AC	BlastBeats
23	AC	4EvrFusion	57	AC	LuvMachine	91	AC	MelODown
24	FX	Laugh Trax	58	WL	DjemBass	92	AC	Wide Open
25	WL	BluePlanet	59	AC	Mo'Brushes	93	AC	2 Funky
26	AC	FunkFX	60	AC	Playback	94	AC	Eleven
27	EL	Dance Mix	61	AC	Gaddzilla	95	AC	RockSolid
28	FX	Shout Out	62	AC	Shafted	96	HY	TexMix
20	AC	Bump N Go	63	AC	PhillyFunk	97	AC	ShakyGrnd
30	FX	MetalBand	64	EL	Dolby	98	AC	Headliner
31	AC	Havana	65	EL	Slam Hop	99	AC	BoardrLine
32	FX	ScaryOscar	66	AC	Tight Grip			
33	AC	WarmNWorn	67	WL	DragnDance			

**KICKS**

Ambient Rock	Big Butt	Piano Rock
Country	Big Smack	Quarter Head
Crunch	Blastbeat	Hard Rock 2
Cust Tiny16"	Blues 1	Rocker
Double Head	Blues 2	RockKik
Dry Bop 18"	Crescent	Room
Energizer	Narrow	RoundBlues
Floppy	Deep	Shred Head
Mpl 90's 20"	Dry	Single Head
Hardware	EastRoom	Slap
HR16 Rock	Flabby	Round
Mpl Damp 26"	Funk Head	Snare & Kick
Low 24"	Funk 1	Solid 1
3ply 60's 22"	Funk 2	Solid 2
Pop 1	FunkPlus	Solid 3
Hard Rock 1	Fusion	Splat
Standard 22"	Pillow	Tite Room
Thump	Growl	Dry Room
Tight 20"	Hmm	Garage
Tighter 20"	Jazz Kick	Stage
7plyBrch 24"	Kuma 1	Studio Kick
Big 26"	Kuma 2	Hard Head
Pop 2	High N Tite	Thick Head
70s Rock	Lo Fi	Thud Head
80s Rock	Lo N Tite	Thumpy
90s Rock	Loose Batter	Thunky
Ambient	Louie Kick	Tight Funk
Thunk	Metal Head	Vocal Kik
Banger	Modern	Warm
Bass N Kick	Noisy	
Big Punch	Jazzy	

**TOMS**

6plyMpl14x14	Brch Mute 14
6plyMpl10x8	BrchPinStp14
6plyMpl12x8	Mpl Mute 16"
3ply60s16x16	FbrGMute 16"
3ply60s 13x9	Brch Mute 16"
Roto 12"	FbrGMute18"
Roto 14"	70s 10"
Roto 16"	70s 12"
Brch 14x12	70s 14"
Brch 16x14	70s 16"
Brch 8x7	Brch Mute 8
Brch 10x8	BrchPinStp8
Brch 12x9	Brch Damp 8"
FbrG 14x10	BrchDampSn8
FbrG 16x16	Roto 12" Dn
FbrG 18x16	Roto 12" Up
FbrGlass Rim	Roto 14" Dn
Mpl 10" Brsh	Roto 14" Up
MplMuteSn10"	Roto 16" Dn
Mpl Mute 10"	Roto 16" Up
MplMuteRim10	Snr+BrshHi 1
Brch Mute 10	Snr+BrshHi 2
BrchPinStp10	Snr+BrshLo 1
Brch Damp 10"	Snr+BrshLo 2
BrchDampSn10	Snr+BrshMid
Mpl 12" Brsh	StSnare Hi 1
Mpl Mute 12"	StSnare Hi 2
Mpl 12" Rim	StSnare Lo 1
Brch Mute 12	StSnare Lo 2
BrchPinStp12	StSnare Mid
Mpl Mute 13"	VocalTom 1
Mpl 14" Brsh	VocalTom 2
6plyMpl14x12	VocalTom Lo
Mpl 14" Rim	VocalTom Mid
FbrGMute 14"	

**SNARES**

Pc3x14SnOfRS	Br 14x5 OpCn	Thonk Dry	Clap Snare	Ringer
Pc3x14SnrOff	Br 14x5 RS	Woody 1	CrescentSnr	Round Blues
90's Rock	Br 14x5xstk	Mpl14x40pCen	Crisp	Shred RS
Bnz 13x6	EWf14x6Stk	Mpl 14x4 RS	DC Funk	Shred Snare
Bnz13x6 RS	EWf14x6StkRS	Mpl14x40fCnt	Deadwood	Side Snare
Bnz13x6	14x6 FFS	70's Rock	Deep Snare	Snare Brush
Mpl14x6 Opn	14x6 FFSRS	80's Rock	East Room	Piccolo 4
Mpl14x6 RS	Piccolo 1	BlastbeatSnr	Flanged	Steel
Chrome 5x14	Piccolo 2	Blues Club	Full	Studio Rim
StStl 14x5	Piccolo 3	Bright 1	Funk Plus	Studio Snare
Stl14x5 BrRS	CmBr14x5 RS	Bright 2	Low Snare 1	Thin Beauty
Stl14x5 Brsh	CmBr14x5Stk	Brush Jazz	Low Snare 2	Tight
StStl14x5 RS	CmBr14x5RdRS	Brush JazzRS	MarchingBand	Vocal Snare
AL 14x5 Rd	Db14x7 Damp	Brush Lite	Meaty	Vocal SnrRS
AL 14x5 RS	Db14x7 OpCnt	Brush LiteRS	Philly Funk	Wooden
Br 14x5 Damp	Db14x7 RSDmp	Brush Snr	Piccolo 5	Wood Rim
Br 14x5 OfCn	Piccolo 6	Brush Snr RS	Present	Woody 2



RBM-20 INSTRUMENTS

**CRASHES**

H Xtreme 17" Big Crash  
 S Fierce 16" Big Mallet  
 Z AC Stk 16" Chokey  
 Z KCon 18" Dark Mallet  
 Z Kdark 16" Dark Splash  
 Z Kdark 17" Flange Cym  
 Z KDrkBsh17" Flange Sizzl  
 Z KDrkMlt17" HHX Splash  
 16" Darker Mallet Crash  
 16" Thin Raspy Crash  
 17" AC Stick Sizzle  
 17" DarkStik Small Crash  
 17" KD Dark Splashy  
 17" KD Lite Stereo Crash  
 17" KDBrshLt StfI Crash  
 17" Thin Vintage  
 18" Mallet Vocal Crash  
 20" Crash ZCon Splash

**RIDES**

BosAntiq 20" Z K Thin 22"  
 H HvyStk 21" Z HVCrsh 22"  
 H JzBrsh 22" Big Stick  
 H MdSizzl18" China Ride  
 Z KHiDef 22" Crazy  
 Z Klstnbl20" Electro  
 Z Kthin 20" Ethno  
 Jazz Brush Flange  
 Z KZ 18" Glass Ride  
 Z KHiDef 20" Large  
 B HVCrsh 20" Mark Tree FX  
 CrashRid 20" Piatti Ride  
 Z HVCrsh 20" Stub  
 BosAntiq 22" Vocal Ride

**HI-HATS**

SFusion 13" Hybrid 1  
 Z60sNB 15" Hybrid 2  
 ZManhatn 14" Jazz Hat  
 ZReMix 12" Orchestral  
 ZBrush60s14" Raspy  
 China Hat Chunky  
 VintageElect Lite  
 Crazy Hat Techno  
 Electro 1 Thick  
 Electro 2 Thin  
 Ethnic Tiny  
 Heavy 1 Vocal Hat  
 Heavy 2

**CHINAS/SPLASHES**

SChnaMal 18" ZSplash 10" Flange China SSplash 12"  
 WChina 17" Big China Gong China WSplash  
 WChnaRvt 18" China China Hi China Stk Z Stick 8"  
 WSplash 10"

**BASS**

And Mogue Slap Bass 2  
 Bass Harm Slap Bass 3  
 Bassic SlapNPop 1  
 ChrsFretless SlapNPop 2  
 Crunch Bass Snick Attack  
 Damp Pick Syn Bass 1  
 Drum Bass Syn Bass 2  
 ElectrcBass1 TB Three  
 ElectrcBass2 Trance  
 Electrolyte Upright Bass  
 Fretless Jazz Upright  
 Mazzo Ch Pick  
 MellowUprght ElectrolytCh  
 Mini Bass 1 Mini Bass 6  
 Mini Bass 2 Mini Bass 7  
 Mini Bass 3 Mini Bass 8  
 Mini Bass 4 Mini Bs1 Ch  
 Mini Bass 5 Mini Bs2 Ch  
 Open Jazz Mini Bs3 Ch  
 Pick Bass 1 Mini Bs4 Ch  
 Pick Bass 2 Mini Bs5 Ch  
 Pick Bass 3 Oct Bass  
 Pick Bass 4 Rattle VSw  
 Pick Bass 5 Syn Bs1 Ch  
 Pro Phat Syn Bs2 Ch  
 Rattle Bass  
 Series 900  
 Silver Box  
 Sine Bass  
 Slap Bass 1

**BEATBOX**

08 Clap SDS Tom Hi  
 08 Clave SDS Tom Lo  
 08 Conga Hi SDS Tom Md  
 08 Conga Lo 08 Clap Sn  
 08 Conga Md 08 Cymbal  
 08 Cowbell SDS Crak Snr  
 08 HiHat SDS Deep Kik  
 08 Kick Long Fng Tom Hi  
 08 Kick Shrt Fng Tom Lo  
 08 Maracas Fng Tom Md  
 08 Snare Hex Tom 1 Hi  
 08 Tom Hi Hex Tom 1 Lo  
 08 Tom Lo Hex Tom 1 Md  
 08 Tom Md Hex Tom 2 Hi  
 09 HiHat Hex Tom 2 Lo  
 09 Kick Long Hex Tom 2 Md  
 09 Kick Shrt Hex Tom 3 Hi  
 09 Rim Hex Tom 3 Lo  
 09 Snare Hex Tom 3 Md  
 09 Tom Hi SDS08 Snr  
 09 Tom Lo SDS09 Snr  
 09 Tom Md SDS Kick 4  
 SDS Crack SDS Tom 1  
 SDS Kick 1 SDS Tom 3  
 SDS Kick 2 SolidSDSKik  
 SDS Kick 3  
 SDS Snare 1  
 SDS Snare 2  
 SDS Snare 3  
 SDS Tom 2

**RANDOM**

Hi Conga Rnd  
 Hi Timb Rnd  
 Indian Rnd  
 Lo Conga Rnd  
 Lo Timb Rnd  
 Agogo Rnd  
 Bongo Rnd  
 Clavlick  
 Conga Seq  
 CowBell Rnd  
 Deep Gtr  
 Djembe Seq  
 Funk Gtr 1  
 Funk Gtr 2  
 Funk Horns  
 Funk Synth  
 Funky Gtr  
 Gtr Chunks  
 Gtr Comp  
 HipHop Voc 1  
 HipHop Voc 2  
 Indo Pan  
 Metal GtrSeq  
 Pan Timb  
 Punk Gtr  
 Rock Cmp  
 Scratch Rnd  
 Shaker Rnd  
 Timbal Rnd  
 Udu Seq  
 Zep Gtr

## PERCUSSION

2way Cowbell	LrgTriangle0	TimbaleHiRim	Steel Pan G3
Agogo	Maracas	TimbaleLoRim	Xylo
Agogo Hi	Nagara	TmbourneMte1	Car Crash
Agogo Lo	NativeAmrcan	TmbourneMte2	CarHornLong
Bead Shaker	Finger Snap	TmbrmFngrMte	CarHornShort
Block 1	Oil Can	TmbrmFngrOpn	Car Skid
Block 2	Okedo Taiko	TmbrmStckMte	Dog Bark
Block Mallet	Paah	TmbrmStckOpn	Door Slam
BoLanGoo	PandeiroMute	Triangle Cl	Glass
Bongo HiOpen	PandeiroOpen	Triangle Op	Gun Shot
Bongo HiSlap	PandeiroTap	Tympani 1	Thunder
Bongo LoOpen	Power Snap	Tympani 2	Rev Crash
Bongo LoSlap	Rattle	Tympani 3	Rev Crash Fl
Breketa	Reco Reco	Tympani 4	Rev PicSnare
Bulb Horn	Shaker 1	Udu Hole 1	Rev Ride
Cabasa 1	Shaker 2	Udu Hole 2	Rev Ride Fl
Cabasa 2	Shaker 3	Udu Slap 1	Rev Snare
Cast Roll	Shaker 4	Udu Slap 2	
Chinese Cym1	Shaker 5	Udu SlapHole	
Chinese Cym2	Shaker 6	Udu Top	
Chinese Drum	Shaker Hi	Vibraslap	
Claves	Shaker Lo	Whistle Long	
Conga HiMute	Shime Taiko	Whistle Shrt	
Conga HiOpen	Sleigh Bell	BellTree Dn	
Conga HiSlap	SmTriangleM	BellTree Up	
Conga LoMute	SmTriangle0	Wood Block	
Conga LoOpen	Stereo Clap	Agogo Lo 2	
Conga LoSlap	Stick Click	Cuica Dn	
Congo Bongo	Surdo 1	Cuica Up	
Cowbell 1	Surdo 2	Djembe 4	
Cowbell 2	Syn Shakr	Doumbek 3	
Cowbell 3	Tabla 1	Drum Stix	
Crasher	Tabla 2	FingrTriangl	
Djembe 1	Tabla 3	Gong High	
Djembe 2	Tabla 4	Gong Low	
Djembe 3	Tabla 5	Orch Bass 1	
Doumbek 1	Tabla 6	Orch Bass 2	
Doumbek 2	Tabla Ga	Orch Bell	
Duck Call	Tabla Ka	Orch Cymbal	
Duck Snort	Tabla Na	Orch Snare	
FingerCymbal	Tabla Te	Orch Snr Rim	
Flextone	Talk Drum	Tabla Tin 1	
Ghatam	Tamb Mute	Tabla Tin 2	
Gong	Tamb Open	Tabla Tin 3	
Guiro 1	Tambourine	Triang Mt Hi	
Guiro 2	Tavil	Triang Op Hi	
HiraTaiko36"	Temple Block	Marimba C3	
HR Snap	TimbaleHi 1	Marimba C4	
HiraTaiko60"	TimbaleHi 2	Marimba G2	
Lite Snap	TimbaleHi 3	Marimba G3	
Low Tamb	TimbaleLo 1	Steel Pan A3	
LrgTriangleM	TimbaleLo 2	Steel Pan E3	

## ELECTRO

78 Metal	Scratch 3
CiTekHat	Scratch 4
CiSynHat	Slo Yeh
EleKick 1	Tek Hit 1
EleKick 2	Tek Hit 2
Fresh	Tek Hit 3
Ha	Tek Hit 4
Hmm Kik	Tek Hit 5
HipHop Kik 1	Tek Hit 6
HipHop Kik 2	Tek Hit 7
HipHop Kik 3	Tek Stk
HipHop Kik 4	Ugh
HipHop Kik 5	Vox Snare
HipHop Kik 6	Wah Gtr 1
HipHop Kik 7	Wah Gtr 2
HipHop Kik 8	Yeah
HipHop Snr 1	Synth Tamb
HipHop Snr 2	Dance Snare
HipHop Snr 3	E Piano
House Kick	GM Mod
Jyeah	Grunge Snare
LoFi Snare	HipHop Snr 4
Mtek Hi Hat	Tek Kick
Muscle 5th	Whack
Robot Snare	EthnoTekRide
SciFi 1	Op Syn Hit
SciFi 2	Tek Hat
SciFi 3	Zap Kick
SciFi 4	Grunt
Scratch 1	HRB Snare
Scratch 2	Shape Noise

# HITS

A Gtr Chk 1	Blues Gtr 10	StankyClav 5	HipHp1 Syn04	Jz GtrHrn A	FusnHrn4th3
A Gtr Chk 2	Blues Gtr 11	StankyGtr 01	HipHp1 Vox01	Jz GtrHrn Bb	FusnHrn4th4
A Gtr Chk 3	Blues Gtr 12	StankyGtr 02	HipHp1 Vox02	Jz GtrHrn C	FusnHrnMn3d
A Gtr Chk 4	Blues Shuffl	StankyGtr 03	HipHp1 Vox03	Jz GtrHrn D	FusnHrnOctB
A Pwr Gtr 1	BosNovaEP 01	StankyGtr 04	HipHp1 Vox04	Jz GtrHrn E	FusnHrnOctBb
A Pwr Gtr 2	BosNovaEP 02	StankyGtr 05	HipHp1 Vox05	Jz GtrHrn Eb	FusnHrnOctC
A Pwr Gtr 3	BosNovaEP 03	StankyGtr 06	HipHp1 Vox06	Jz GtrHrn F	FusnHrnOctD1
A Pwr Gtr 4	BosNovaEP 04	StankyGtr 07	R&G Sfx 1	Jz GtrHrn G1	FusnHrnOctD2
A Pwr Gtr 5	BosNovaEP 05	StankyGtr 08	R&G Sfx 2	Jz GtrHrn G2	FusnHrnOctF#
A Pwr Gtr 6	BosNovaEP 06	StankyGtr 09	R&G Sfx 3	Jz Pno BassC	FusnHrnOctF
Funk Jazz	BosNovaEP 07	StankyGtr 10	R&G Sfx 4	Jz Pno BbMj7	FusnHrnOctG
FJ EP 01	BosNovaEP 08	StankyGtr 11	R&G Sfx 5	Jz Pno Bmin7	Fusion 1
FJ EP 02	BosNovaEP 09	StankyGtr 12	R&G Sfx 6	Jz Pno DMaj	Strait Blues
FJ EP 03	BosNovaEP 10	StankyGtr 13	R&G Sfx 7	Jz Pno DMaj7	UrbnGtr Bb2
FJ EP 04	BosNovaEP 11	StankyHrms 1	R&G Sfx 8	Jz Pno EbMj7	UrbnGtr C3
FJ EP 05	BosNovaEP 12	StankyHrms 2	R&G Sfx 9	Jz Pno Emin7	UrbnGtr D3
FJ EP 06	BosNovaEP 13	StankyHrms 3	R&G Syn 1	Punk	UrbnGtr Eb3
FJ EP 07	BosNovaEP 14	StankySyn 1	R&G Syn 2	Punk Gtr 01	UrbnGtr G2
FJ Guitar 01	Bossa Nova	StankySyn 2	R&G Syn 3	Punk Gtr 02	UrbnGtr G3
FJ Guitar 02	C Ac Gtr 01	StankySyn 3	R&G Syn 4	Punk Gtr 03	UrbnGtr Cmi7
FJ Guitar 03	C Ac Gtr 02	StankySyn 4	R&G Syn 5	Punk Gtr 04	UrbnGtr Gmin
FJ Guitar 04	C Ac Gtr 03	StankySyn 5	R&G Vox 1	Punk Gtr 05	UrbnSyn Cmin
FJ Guitar 05	C Ac Gtr 04	StankySyn 6	R&G Vox 2	Punk Gtr 06	UrbnSyn D
FJ Guitar 06	C Ac Gtr 05	GetUppla!Gtr1	R&G Vox 3	Punk Gtr 07	UrbnSyn Eb
FJ Guitar 07	C Ac Gtr 06	GetUppla!Gtr2	R&G VSyn 1	Punk Gtr 08	UrbnSyn F
FJ Guitar 08	C Ac Gtr 07	GetUppla!Gtr3	R&G VSyn 2	Punk Gtr 09	UrbnSyn Gmin
FJ Guitar 09	C Ac Gtr 08	GetUppla!Gtr4	R&G VSyn 3	Punk Gtr 10	Urban
FJ Guitar 10	C Ac Gtr 09	GetUppla!Gtr5	R&G VSyn 4	SB Gtr Fx 01	J-Bon
Indie Rock	C Ac Gtr 10	GetUppla!Gtr6	R&G VSyn 5	SB Gtr Fx 02	J-Bon Gtr 1
SM Gtr 01	C Ac Gtr 11	GetUppla!Gtr7	House 1	SB Gtr Fx 03	J-Bon Gtr 2
SM Gtr 02	C El Gtr 01	GetUppla!Gtr8	House EP 1	SB Gtr Fx 04	J-Bon Gtr 3
SM Gtr 03	C El Gtr 02	GetUppla!Org1	House EP 2	SB Gtr Fx 05	J-Bon Gtr 4
SM Gtr 04	C El Gtr 03	GetUppla!Org2	House EP 3	SB Gtr Fx 06	J-Bon Gtr 5
SM Gtr 05	C El Gtr 04	GetUppla!Org3	House EP 4	SB Gtr Fx 07	J-Bon Gtr 6
SM Gtr 06	C El Gtr 05	GetUppla!Org4	House EP 5	SB Gtr Fx 08	J-Bon Gtr 7
SM Gtr 07	C El Gtr 06	GetUppla!Org5	House Gtr 1	SB Gtr Fx 09	5-4 Jazz
SM Gtr 08	C El Gtr 07	GetUppla!Org6	House Gtr 2	SB Gtr Fx 10	All AcGuitar
SM Gtr 09	Country Gtrs	Stanky	House Gtr 3	SB Gtr Fx 11	All CleanGtr
SM Gtr 10	Jal Gtr 01	Get Uppla!	House Gtr 4	SB Gtr Fx 12	All EPs
SM Gtr 11	Jal Gtr 02	Hip Hop 1	House Gtr 5	SB Gtr Fx 13	All HeavyGtr
SM Gtr 12	Jal Gtr 03	Hip Hop 2	House Gtr 6	SB Gtr Fx 14	All Horns
SM Gtr 13	Jal Gtr 04	HipHp1 Gtr01	House Syn 1	SB Gtr Fx 15	Funk 8
SM Gtr 14	Jal Gtr 05	HipHp1 Gtr10	House Syn 2	SB Gtr Fx 16	House 2
SM Gtr 15	Jal Gtr 06	HipHp1 Gtr11	House Syn 3	SB Gtr Fx 17	RnB 5
Slow Metal	Jal Gtr 07	HipHp1 Gtr12	Jazz	SB Gtr Fx 18	All MarimbaH
Bass Slide 1	Jal Gtr 08	HipHp1 Gtr13	Jazz Waltz	SB Gtr Fx 19	All MarimbaL
Bass Slide 2	Jalape±±o	HipHp1 Gtr14	JW Vibes A2	SB Gtr Fx 20	All SteelDrm
Bass Slide 3	70sHRCombo 1	HipHp1 Gtr15	JW Vibes Ab2	FusnEP Amin	All Xylophne
Bass Slide 4	70sHRCombo 2	HipHp1 Gtr16	JW Vibes Ab3	FusnEP BbMaj	All OrchBell
Bass Slide 5	70sHRCombo 3	HipHp1 Gtr17	JW Vibes Bb2	FusnEP Bmin	All Slides
Bass Slide 6	70sHRCombo 4	HipHp1 Gtr02	JW Vibes Bb3	Fusion Gtr 1	All Vibes Hi
Bass Slide 7	70sHRCombo 5	HipHp1 Gtr03	JW Vibes C3	Fusion Gtr 2	All Vibes Lo
Blues Gtr 01	70sHRCombo 6	HipHp1 Gtr04	JW Vibes D3	Fusion Gtr 3	
Blues Gtr 02	70sHR Gtr 1	HipHp1 Gtr05	JW Vibes Eb3	Fusion Gtr 4	
Blues Gtr 03	70sHR Gtr 2	HipHp1 Gtr06	JW Vibes F3	Fusion Gtr 5	
Blues Gtr 04	70sHR Gtr 3	HipHp1 Gtr07	JW Vibes G2	Fusion Gtr 6	
Blues Gtr 05	70sHardRock	HipHp1 Gtr08	JW Vibes G3	Fusion Gtr 7	
Blues Gtr 06	StankyClav 1	HipHp1 Gtr09	Jz GtHn EbM7	Fusion Gtr 8	
Blues Gtr 07	StankyClav 2	HipHp1 Syn01	Jz GtHn Emin	Fusion Gtr 9	
Blues Gtr 08	StankyClav 3	HipHp1 Syn02	Jz GtHn F#m	FusnHrn4th1	
Blues Gtr 09	StankyClav 4	HipHp1 Syn03	Jz GtHn FMj7	FusnHrn4th2	

***Pearl***

Copyright 2010 Pearl Corporation. All rights reserved